







































































Original		Replacement		Original		Replacement	
	Power		Power		8		8
	Mute		Mute / Dimmer		9		9
	Play / [≡]		Play / Slow		Info		Info / Angle
	Pause / [T.S]		Pause / Step / Freeze		0		0
	Stop / [≡]		Stop / Hold		EPG		Guide / EPG / -/-
	Rec / [≡↕]		Rec / Rec Mode		Settings ⚙		Setup / OPT /
	<< / [≡⊕]		<< / Tune-		Settings ⚙		Display / Media
	<< / [≡i]		<< / Preset-		Input		AV / Input / RDS
	>> / [≡?]		>> / Preset+		Up		Up
	>> / [≡X]		>> / Tune+		Left		Left
	1		1		OK		OK
	2		2		Right		Right
	3		3		Down		Down
	4		4		≡		D.Menu / Top
	5		5		Google Assist		Smart / List
	6		6		←		Back / Return
	7		7		Vol+		Vol+



