Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Power ON/Off	Power	Volume-	Vol -
CD Play	Play / Slow	Display	Display / Media
CD Pause	Pause / Step / Freeze	Vol Rs-/Effect	CH- / Page-
CD Rewind	<< / Tune-	Pr 1	1
CD F.FWD	>> / Tune+	Pr 2	2
Tape 2 Pre./eq	Subtitle / EQ	Pr 3	3
6 Ch/Geq	Eject / Surround	Pr 4	4
Sleep	Sleep / Timer	Pr 5	5
Program	TV/Radio /	Pr 6	6
Store/Center-	D.Menu / Top	Pr 7	7
CD/Theater	AV / Input / RDS	Pr 8	8
Mode	Menu / Home	Pr 9	9
Tape 1 Hall/Ats	Info / Angle	Pr 0/10	0
Tape 1 Play	OK	Repeat	Green / APP / Repeat
Tape 1 F.FWD	Right	CD Random	Blue / Prime Video / Random
Volume+	Vol +		
Funct./Direct	Smart / List		

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Power ON/Off	Power	Pr 1	1
Mute	Mute / Dimmer	Pr 2	2
CD Play	Play / Slow	Pr 3	3
Stop	Stop / Hold	Pr 4	4
CD Rewind	<< / Tune-	Pr 5	5
CD F.FWD	>> / Tune+	Pr 6	6
Tape 2 Pre./eq	Subtitle / EQ	Pr 7	7
Input/Source	AV / Input / RDS	Pr 8	8
Tape 1 Hall/Ats	Menu / Home	Tuner/Bypass	Red / Netflix / Search
Tape 1 Rew	Left	Band	Green / APP / Repeat
Tape 1 Play	OK	Fm Mode/Disc	Yellow / YouTube / Repeat
Tape 1 F.FWD	Right	Phono/Scan	Blue / Prime Video / Random
Tape 1 Stop	Down		
Volume+	Vol +		
Funct./Direct	Smart / List		
Volume-	Vol -		
CD/Theater	Display / Media		

Originalfernbedienung	Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung	
Power ON/Off		Power	Program	PROGRAM TV/RADIO	TV/Radio /
Mute	DIMMER MUTE	Mute / Dimmer	Every Pop	TOP MENU D.MENU	D.Menu / Top
CD Play	SLOW ▶	Play / Slow	6 Ch/Geq	OPT-TOOLS SETUP	Setup / OPT /
CD Pause	STEP-FREEZE ⏸	Pause / Step / Freeze	Surround/Test	GOTO TEXT	Text / Goto
Stop	HOLD ■	Stop / Hold	Input/Source	RDS AV INPUT	AV / Input / RDS
Tape 1 Rec	REC MODE ●	Rec / Rec Mode	CD/Theater	HOME MENU	Menu / Home
CD Rewind	TUNE- ◀◀	<< / Tune-	Erase/Snooze	▲	Up
CD F.FWD	TUNE+ ▶▶	>> / Tune+	Tape 1 Preset	ANGLE INFO	Info / Angle
Prev./Prog-	PRESET- ⏮	I<< / Preset-	Tape 1 Rew	◀	Left
Next/Prog+	PRESET+ ⏭	>>I / Preset+	Tape 1 Play	OK	OK
Intro	TITLE SOUND	Sound / Title	Tape 1 F.FWD	▶	Right
Classic Track	LANG I/II AUDIO	Audio / Lang I/II	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
Tape 2 Pre./eq	EQ SUBTITLE	Subtitle / EQ	Tape 1 Stop	▼	Down
Eject	SURROUND ⏏	Eject / Surround	Mark/Delete	RETURN BACK	Back / Return
Edit	FORMAT PICTURE	Picture / Format	Volume+	+ VOL	Vol +
Woofer/Speed	SIZE ZOOM	Zoom / Size	Funct./Direct	LIST SMART	Smart / List
Sleep	TIMER SLEEP	Sleep / Timer	Index+/Vol Ls+	+ CH PAGE	CH+ / Page+

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Volume-	VOL − Vol -	Ubs/Check	YouTube REPEAT A-B Yellow / YouTube / Repeat
Display	MEDIA DISPLAY Display / Media	CD Random	Prime Video RANDOM Blue / Prime Video / Random
Index-/Vol Ls-	CH PAGE − CH- / Page-	ON/Off	SHIFT + Shift + Power
Pr 1	TV 1 1	Dimmer	SHIFT + DIMMER MUTE Shift + Mute / Dimmer
Pr 2	DVD 2 2	Preset Pause	SHIFT + STEP-FREEZE ⏸ Shift + Pause / Step /
Pr 3	CD-STB 3 3	Tape 2 REC./Jazz	SHIFT + REC MODE Shift + Rec / Rec Mode
Phono/Scan	VIDEO 4 4	Tune/Vol SW+	SHIFT + TUNE- ◀◀ Shift + << /
Center	TAPE 5 5	Tune/Vol SW-	SHIFT + TUNE+ ▶▶ Shift + >> /
Fm Mode/Disc	TUNER 6 6	Track-/Echo	SHIFT + PRESET- ⏮ Shift + I<< / Preset-
Aux/Video	AUX-HDD 7 7	Track+/Karaoke	SHIFT + PRESET+ ⏭ Shift + >>I / Preset+
Space/Default 3D	USB 8 8	Disc 1 Eject	SHIFT + SURROUND ⏏ Shift + Eject / Surround
Tuner/Bypass	BLUETOOTH 9 9	Timer/A.Track	SHIFT + TIMER SLEEP Shift + Sleep / Timer
+10/Next Sv+V	-/-- GUIDE EPG Guide / EPG / -/--	X-Bass/Bgm	SHIFT + ▲ Shift + Up
Store/Center-	HDMI-SAT 0 0	Tape 1 Hall/Ats	SHIFT + ANGLE INFO Shift + Info / Angle
Mode	PC FAV MARKER Fav / Marker / PC	Tape 2	SHIFT + ◀ Shift + Left
Search/Center	NETFLIX SEARCH Red / Netflix / Search	Tape 2	SHIFT + OK Shift + OK
Repeat	APP REPEAT Green / APP / Repeat	Tape 2 FF/AudioR	SHIFT + ▶ Shift + Right

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Tape 2	SHIFT + ▼		
Vol Rs+/S. Mode	SHIFT + VOL +		
Vol Rs-/Effect	SHIFT + VOL −		
Disc 2	SHIFT + 2		
Disc 3 Eject	SHIFT + 3		
Disc 4 Eject	SHIFT + 4		
Disc 5	SHIFT + 5		
Band	SHIFT + 6		