Mandis shop

Samsung AH5902692A

Original		Replacement		Original	Replacement
	Power		Power		
	Source	TIMER AV	AV		
VOL	Vol +	VOL +	Vol +		
VOL	Vol -	VOL −	Vol -		
	Mute	MUTE	Mute		
	Back	RETURN BACK	Back		
	Play	PLAY MODE ▶	Play		
	Pause	II	Pause		
	I<<	I<<	I<<		
	>>I	>>I	>>I		
SOUND	Sound	SOUND DUAL	Dual		
SOUND EFFECT	Sound Effect	SETTINGS OPT	Options		
SOUND CONTROL	Sound Control	AD SUBT	Subt		
WOOFER	Woofer	HOME SMART	Smart		
STREAMING MUSIC	Streaming	REPEAT TEXT	Text		
Anynet+	Anynet+	APP MEDIA	Media		