Original		Replacement	
	Power		Power
TV ASPECT	Tv Aspect/AV In	ECO 3D	3D
TV/TEXT	Tv/Text	REPEAT TEXT	Text
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
INPUT SELECT AV	AV/Input Selec	TIMER AV	AV
-/--	-/--	-/-- GUIDE	Guide
VOLUME +	Vol +	+ VOL	Vol +
	Vol -	VOL -	Vol -

Original		Replacement	
CKING/V-LOCK +	Tracking/V. Lock+	+ CH	Ch +
-	Tracking/V. Lock-	CH -	Ch -
	Prog./Check Up	SHIFT + CH +	Shift + Ch +
PROG./CHEC	Prog./Check Down	SHIFT + CH -	Shift + Ch -
	Red	A	Red
+ DATE	Green	B	Green
+ ON	Yellow	C	Yellow
+ OFF	Blue	D	Blue
+ OFF	Off+		Up
OFF -	Off-		Down
+ ON	On+		Right
ON -	On-		Left
+ DATE	Date+	HOME SMART	Smart
DATE -	Date-	APP MEDIA	Media

Original		Replacement	
	Power		Power
DIRECT TV REC	Direct Tv Rec	SEARCH TV/R	TV/R
TV ASPECT	Tv Aspect/AV Lin	ECO 3D	3D
TV/TEXT	Tv/Text	REPEAT TEXT	Text
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	-/-- GUIDE	Guide
INPUT SELECT AV	AV/Input Selec	TIMER AV	AV
CKING/V-LOCK +	Tracking/V-Lock+	+ CH	Ch +

Original		Replacement	
	Tracking/V-Lock-	CH −	Ch -
VOLUME +	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -
LIBRARY/SEARCH	Library/Search	HOME SMART	Smart
INDE	I<< Index		I<<
DEX	Index >>I		>>I
SV/V+	SV/V+	APP MEDIA	Media
STILL ALBUM	--/Still Albu	RETURN BACK	Back
REPLAY	Replay	AD SUBT	Subt
	Pause/Step		Pause
REC	Rec	REC MODE	Rec
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
	Play	PLAY MODE	Play

Original		Replacement	
	Stop		Stop
	>>		>>
	<<		<<
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
	Prog. / Check Up	SHIFT + CH +	Shift + Ch +
PROG./CHEC	Prog. / Check Down	SHIFT + CH -	Shift + Ch -
+ DATE	Date+	SHIFT + HOME SMART	Shift + Smart
DATE -	Date-	SHIFT + APP MEDIA	Shift + Media
+ ON	On+	B	Green
ON -	On-	A	Red
+ OFF	Off+	D	Blue
OFF -	Off-	C	Yellow
PROG./CHECK	Prog. Check	PROG SLEEP	Sleep
CANCEL	Cancel	DISC NAV LIST	List
SP/LP/EP	SP/ LP/ EP	PICTURE FORMAT	Format
TIMER	Timer	SHIFT + TIMER AV	Shift + AV

Original		Replacement	
I-TIMER	I-Timer	SETTINGS OPT	Options
AUDIO	Audio	SOUND DUAL	Dual
OSD/DISPLAY	OSD/Display	DISPLAY INFO	Info
RESET	Reset	E-MANUAL D.MENU	D. Menu