Original		Replacement	
Power		Power	
Power Tv		SHIFT +	Shift + Power
TV/VIDEO	Tv/Video Tv	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
DVD	DVD/2nd Select	NETFLIX SEARCH	Red / Netflix / Search
FM/AM	FM/AM	APP REPEAT	Green / APP / Repeat
iPod	i Pod	YouTube REPEAT A-B	Yellow / YouTube / Repeat
VOL +	Vol + Tv	SHIFT +	Shift + Right
VOL -	Vol - Tv	SHIFT +	Shift + Left
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Replacement	
0	0	HDMI-SAT 0	0
≥10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
DISC	Disc/CD Mode	Prime Video RANDOM	Blue / Prime Video / Random
SELECT >	Select >	CH PAGE +	CH+ / Page+
SELECT <	< Select	CH PAGE -	CH- / Page-
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
CD MODE	I<<	PRESET-	I<< / Preset-
>>I	>>I	PRESET+	>>I / Preset+
<<	<<	TUNE-	<< / Tune-
>>	>>	TUNE+	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
ONE TOUCH PLAY	One Touch Play	PC FAV MARKER	Fav / Marker / PC
MENU PLAY LIST	Menu/Play List	HOME MENU	Menu / Home

Original		Replacement		Original		Replacement	
RETURN	Return	RETURN BACK	Back / Return				
TOP MENU DIRECT NAVIGATOR	Top Menu/Direct Navigator	LIST SMART	Smart / List				
START	Start	ANGLE INFO	Info / Angle				
FUNCTIONS	Functions	TOP MENU D.MENU	D.Menu / Top				
▲	Up	▲	Up				
▼	Down	▼	Down				
▶	Right/I>	▶	Right				
◀	Left/<I	◀	Left				
OK	OK	OK	OK				
SOUND	Sound	TITLE SOUND	Sound / Title				
PLII	Dolby PLII	EQ SUBTITLE	Subtitle / EQ				
PLAY MODE REPEAT	Play Mode/Repeat	GOTO TEXT	Text / Goto				
FL DISPLAY	FL Display	SIZE ZOOM	Zoom / Size				
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
W.S. SLEEP	W.S./Sleep	PROGRAM TV/RADIO	TV/Radio /				
SUBWOOFER LEVEL CH SELECT	Level/Subwoofer/CH Select	FORMAT PICTURE	Picture / Format				
MUTING	Muting	DIMMER MUTE	Mute / Dimmer				