Original		Replacement	
POWER	Power		Power
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
CLOCK 1	1	TV 1	1
CLOCK 1	Clock	OPT-TOOLS SETUP	Setup / OPT /
TIMER 2	2	DVD 2	2
TIMER 2	Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
3	3	CD - STB 3	3
TUNER MODE 4	4	VIDEO 4	4
TUNER MODE 4	Tuner Mode	ANGLE INFO	Info / Angle
REV MODE 5	5	TAPE 5	5
REV MODE 5	Rev Mode	RETURN BACK	Back / Return
RESUME 6	Resume	HOME MENU	Menu / Home
RESUME 6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
>10	+10	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement	
CD EDIT/CHECK 10/0	10/0	HDMI - SAT 0	0
CD EDIT/CHECK 10/0	CD Edit/Check	GOTO TEXT	Text / Goto
CLEAR	Shift Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SHUFFLE / PROGRAM	Shuffle/Program	Prime Video RANDOM	Blue / Prime Video / Random
SHUFFLE / PROGRAM	Shuffle/Program	PROGRAM TV/ RADIO	TV/Radio /
PRESET	Preset Up	SHIFT + PRESET+	Shift + >>I / Preset+
PRESET	Preset Up		Up
PRESET	Preset Down		Down
I<</<<		TUNE-	<< / Tune-
I<</<<		PRESET-	I<< / Preset-
I<</<<			Left
ENTER	Enter	OK	OK
>>/>>I		TUNE+	>> / Tune+
>>/>>I			Right
>>/>>I		PRESET+	>>I / Preset+
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

Original		Replacement		Original	Replacement
PRESET	Preset Down	SHIFT + PRESET-	Shift + I<< / Preset-		
CD ▶II	Play/Pause CD	STEP - FREEZE II	Pause / Step / Freeze		
CD ▶II	Play/Pause CD	SLOW ▶	Play / Slow		
TAPE ◀▶	<> Tape	SHIFT + SLOW ▶	Shift + Play /		
■	Stop	HOLD ■	Stop / Hold		
TUNER BAND	Tuner/Band	SHIFT + TUNER 6	Shift + 6		
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7		
FUNCTION	Function	LIST SMART	Smart / List		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer		
VOLUME +	Vol+	+ VOL	Vol+		
SHIFT	Shift	TOP MENU D.MENU	D.Menu / Top		
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer		
−	Vol-	VOL −	Vol-		