Mandis shop

REMCON1483

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | [ ] | Picture / Format |
| Mode | Smart / List | ♫ | Audio / Lang I/II |
| Rotate | Green / APP / Repeat | [ ]♫ | TV/Radio / |
| Setup | Setup / OPT / | Vol - | Vol - |
| Up | Up | Mute | Mute / Dimmer |
| Zoom | Zoom / Size | Vol + | Vol + |
| Left | Left | | |
| Enter | OK | | |
| Play | Play / Slow | | |
| Pause | Pause / Step / Freeze | | |
| Right | Right | | |
| Timer | Sleep / Timer | | |
| Down | Down | | |
| Back | Back / Return | | |
| I<< | I<< / Preset- | | |
| [O] | Subtitle / EQ | | |
| >>I | >>I / Preset+ | | |

https://aleferlademando.de/Belson/106148375-replacement-remote-control-for-Belson-REMCON1483.htm