Originalfernbedienung		Ersatzfernbedienung	
POWER	Power		Power
TV POWER	Power Tv	SHIFT +	Shift + Power
DVD	DVD	SHIFT + DVD 2	Shift + 2
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
EJECT OPEN/CLOSE	Eject/Open-Close	SURROUND	Eject / Surround
AV/INPUT	AV Input Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
PR	PR+ Tv	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
	PR- Tv	CH PAGE −	CH- / Page-
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Originalfernbedienung		Ersatzfernbedienung	
VOL	Vol+ Tv	+ VOL	Vol+
REC	Rec	REC MODE	Rec / Rec Mode
0	0	HDMI - SAT 0	0
AV/INPUT	AV Input	RDS AV INPUT	AV / Input / RDS
	Vol- Tv	VOL −	Vol-
<< Scan		TUNE- <<	<< / Tune-
Scan >>		TUNE+ >>	>> / Tune+
I<< Skip		PRESET- I<<	I<< / Preset-
Skip >>I		PRESET+ >>I	>>I / Preset+
PAUSE/STEP	Pause/Step	STEP - FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow
STOP	Stop	HOLD	Stop / Hold
HOME	Home	HOME MENU	Menu / Home
	PR/TRK+	SHIFT + + CH PAGE	Shift + CH+ /
	Up		Up
MENU/LIST	Menu/List	TOP MENU D.MENU	D.Menu / Top
	Left		Left

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
ENTER	Enter	OK	OK		
	Right		Right		
RETURN	Return	RETURN BACK	Back / Return		
	Down		Down		
	PR/TRK-	SHIFT +	CH PAGE – Shift + CH- /		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		
AUDIO	O))/Audio	LANG I/II AUDIO	Audio / Lang I/II		
TITLE	Title	TITLE SOUND	Sound / Title		
MARKER	Marker	PC FAV MARKER	Fav / Marker / PC		
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
FAV	Red/FAV	NETFLIX SEARCH	Red / Netflix / Search		
REPEAT	Green/Repeat	APP REPEAT	Green / APP / Repeat		
SUBTITLE	Yellow/Subtitle	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
TEXT	Blue/Text	Prime Video RANDOM	Blue / Prime Video / Random		
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--		
DUBBING	Dubbing	LIST SMART	Smart / List		