Originalfernbedienung		Ersatzfernbedienung	
STANDBY	Standby		Power
	Lock	APP / REPEAT	Green / APP / Repeat
MENU	Menu	HOME / MENU	Menu / Home
TIMER ON/OFF	Timer On/Off	TIMER / SLEEP	Sleep / Timer
AUDIO OUT	Audio Out	DIMMER / MUTE	Mute / Dimmer
SKIP SEARCH	Skip Search	NETFLIX / SEARCH	Red / Netflix / Search
ZERO BACK	Zero Back	RETURN / BACK	Back / Return
CLEAR	Clear	CLEAR / EXIT / CANCEL	Exit / Cancel / Clear
	Up		Up
SET	Set	OK	OK
SHOWVIEW	SV/V+/Timer/Showview	FORMAT / PICTURE	Picture / Format
	Down		Down
	Right		Right
	Left		Left
DISPLAY	Display	MEDIA / DISPLAY	Display / Media
1	1	TV / 1	1
MODE OSD	Mode OSD	ANGLE / INFO	Info / Angle

Originalfernbedienung		Ersatzfernbedienung	
2	2	DVD / 2	2
3	3	CD-STB / 3	3
4	4	VIDEO / 4	4
5	5	TAPE / 5	5
6	6	TUNER / 6	6
7	7	AUX-HDD / 7	7
8	8	USB / 8	8
9	9	BLUETOOTH / 9	9
0	0	HDMI-SAT / 0	0
INPUT SELECT	Input Select	RDS / AV INPUT	AV / Input / RDS
REW	<<	TUNE-	<< / Tune-
PLAY/X2	Play	SLOW	Play / Slow
AM/PM	-/--/AM/PM	-/-- / GUIDE EPG	Guide / EPG / -/--
FF	>>	TUNE+	>> / Tune+
REC	Rec	REC MODE	Rec / Rec Mode
CHANNEL	Channel +	CH PAGE +	CH+ / Page+
CHANNEL	Channel -	CH PAGE −	CH- / Page-

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
STOP	Stop	HOLD ■	Stop / Hold		
SLOW	Slow	SHIFT + SLOW ▶	Shift + Play /		
PAUSE/STILL	Pause/Still	STEP-FREEZE ❚❚	Pause / Step / Freeze		
TAPE SPEED	Tape/Speed	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
DPSS ◁	◁ DPSS/-	PRESET- ⏮	I<< / Preset-		
DPSS ▷	DPSS I>/+	PRESET+ ⏭	>>I / Preset+		
TV/VCR	TV/VCR	LIST SMART	Smart / List		
TV OPERATE	Tv Operate	SHIFT + ⏻	Shift + Power		
INPUT SELECT	Tv Input Selec	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS		
CH▲	Tv CH+	SHIFT + + CH PAGE	Shift + CH+ /		
CH▼	Tv CH-	SHIFT + CH PAGE −	Shift + CH- /		
VOL⊖	Tv Vol -	VOL −	Vol -		
VOL⊕	Tv Vol +	+ VOL	Vol +		