Originalfernbedienung	Ersatzfernbedienung
On/Off	Power
Mute	Mute
Reveal	Smart
Subt. List	Subt
Txt Stop	Stop
Info	Shift + Info
Sleep Timer	Sleep
Return TV	TV/R
Menu video	D. Menu
Text	Text
Txt Expand	Eject
Menu	Menu
Menu Up	Up
Display	Info
Menu Left	Left
OK Enter	Ok
Menu Right	Right

Originalfernbedienung	Ersatzfernbedienung
Menu Down	Down
Back	Back
Volume+	Vol +
Chan. Up	Ch +
Volume-	Vol -
Chan. Down	Ch -
Menu audio	Dual
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Guide -/-- 1.	Guide

Originalfernbedienung	Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
0/ 10	0	0		
2. Fav P/ C 2.	FAV PRE-CH	Pre Ch		
Red	A	Red		
Green	B	Green		
Yel l ow	C	Yel l ow		
Bl ue	D	Bl ue		
Tone+	APP MEDIA	Medi a		

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
On/Off	Power	OK Enter	Ok
Mute	Mute	Menu Right	Right
Update	Play	Menu Off	Exit
Reveal	Pause	Menu Down	Down
Txt Stop	Stop	Back	Back
Info	SHIFT + DISPLAY INFO Shift + Info	Volume+	VOL + Vol +
Subt. List	AD SUBT Subt	Chan. Up	CH + Ch +
Sleep Timer	PROG SLEEP Sleep	Volume-	VOL − Vol -
Return TV	SEARCH TV/R TV/R	Menu audio	SOUND DUAL Dual
Menu video	E-MANUAL D.MENU D. Menu	Chan. Down	CH − Ch -
Text	REPEAT TEXT Text	1	1 1
Txt Expand	ZOOM Eject	2	2 2
TV/AV	TIMER AV AV	3	3 3
Menu	TOP MENU MENU Menu	4	4 4
Menu Up	Up	5	5 5
Display	DISPLAY INFO Info	6	6 6
Menu Left	Left	7	7 7

Originalfernbedienung	Ersatzfernbedienung
8	8
9	9
Guide -/-- 1.	GUIDE
0/10	0
2. Fav P/C 2.	FAV PRE-CH
Red	A
Green	B
Yellow	C
Blue	D
On/Off	SHIFT + Power
Rotate Text	SHIFT + MUTE
Audio-	SHIFT + VOL –
On/Tim	REC MODE
Off/Tim	SHIFT + REC MODE
Tone+	>>
Color+ P. Std	SHIFT + PICTURE FORMAT
Tone-	<<

Originalfernbedienung	Ersatzfernbedienung
Audio+	SHIFT + + VOL
Bright+ Mode	>>I
Mix Scan	SHIFT + SEARCH TV/R
Store Text	SHIFT + REPEAT TEXT
Game Coo	SHIFT + ZOOM
AV 2	SHIFT + TIMER AV
Disp	ECO 3D
Search	SHIFT +
Store	SHIFT + HOME SMART
Browse	HOME SMART
Bright- Sys	I <<
Output	SHIFT + APP MEDIA
Input	APP MEDIA
Tune-	SHIFT +
Aft/Caf	SHIFT + OK
Tune+	SHIFT +
Color- S. Std	SHIFT + SOUND DUAL

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Contrast +	SHIFT + CH + (Shift + Ch +)	Level R/Woofer	SHIFT + D (Shift + Blue)
Contrast -	SHIFT + CH − (Shift + Ch -)		
On Pip	SHIFT + 1 (Shift + 1)		
Clear	SHIFT + CLEAR EXIT (Shift + Exit)		
Swap	SHIFT + 2 (Shift + 2)		
Rotate Pip	SHIFT + 3 (Shift + 3)		
Still	SHIFT + 4 (Shift + 4)		
Dim Pip	SHIFT + 5 (Shift + 5)		
Help	SHIFT + 6 (Shift + 6)		
Camera	SHIFT + 7 (Shift + 7)		
Camera1	SHIFT + 8 (Shift + 8)		
3. *	SHIFT + GUIDE (Shift + Guide)		
View	SHIFT + 0 (Shift + 0)		
4. # 16: 9	PICTURE FORMAT (Format)		
Surround	SHIFT + A (Shift + Red)		
Nicam/Mono	SHIFT + B (Shift + Green)		
Level L	SHIFT + C (Shift + Yellow)		