Mandis shop

JVC RMSUXG6R

Originalfernbedienung		Ersatzfernbedienung	
PANEL OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
DIMMER	Dimmer	DIMMER MUTE	Mute / Dimmer
⏻/I	Power		Power
ACTIVE BASS EX.	Active Bass EX.	EQ SUBTITLE	Subtitle / EQ
CLOCK/TIMER	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
BASS	Bass	TITLE SOUND	Sound / Title
TREBLE	Treble	LANG I/II AUDIO	Audio / Lang I/II
FM MODE	FM Mode	+ CH PAGE	CH+ / Page+
PLAY MODE	Play Mode	HOME MENU	Menu / Home
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
AUTO PRESET	Auto Preset	CH PAGE −	CH- / Page-
PTY/EON	PTY/EON	RETURN BACK	Back / Return
TITLE/EDIT	Title/Edit	ANGLE INFO	Info / Angle
ENTER	Enter	LIST SMART	Smart / List
DISPLAY /CHARA.	Display/Chara.	MEDIA DISPLAY	Display / Media
UP	Up	▲	Up

Originalfernbedienung		Ersatzfernbedienung	
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
<	Left	<	Left
SET	Set	OK	OK
>	Right	>	Right
▶/II MD	Play/Pause MD	STEP-FREEZE II	Pause / Step / Freeze
DOWN	Down	▼	Down
AUX	AUX	AUX-HDD 7	7
TAPE	<> Tape	TUNE+ ▶▶	>> / Tune+
FM/AM	FM/AM	TUNER 6	6
CD ▶/II	Play/Pause CD	SLOW ▶	Play / Slow
I<<	I<<	PRESET- I<<	I<< / Preset-
■	Stop	HOLD ■	Stop / Hold
>>I	>>I	PRESET+ >>I	>>I / Preset+
+ VOLUME	Volume+	+ VOL	Vol+
VOLUME −	Volume-	VOL −	Vol-

https://alle-fernbedienungen.de/de/JVC/1065394-12352-ersatzfernbedienung-fur-JVC-RMSUXG6R.html