Originalfernbedienung		Ersatzfernbedienung	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
LANG	Lang	LANG I/II AUDIO	Audio / Lang I/II
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
TIME SHIFT	Time Shift	TOP MENU D.MENU	D.Menu / Top
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TV/RADIO	Tv/Radio	PROGRAM TV/ RADIO	TV/Radio /
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
0	0	HDMI - SAT 0	0
RECALL	Recall	RETURN BACK	Back / Return

Originalfernbedienung		Ersatzfernbedienung	
DEV.LIST	Dev.List	MEDIA DISPLAY	Display / Media
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
TEXT	Text	GOTO TEXT	Text / Goto
AUTO	Auto	OPT-TOOLS SETUP	Setup / OPT /
MENU	Menu	HOME MENU	Menu / Home
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
INFO	Info	ANGLE INFO	Info / Angle
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CH+/▲ Group	Up	▲	Up
CH+/▲ Group	CH+	+ CH PAGE	CH+ / Page+
V- ◀	Left	◀	Left
V- ◀	Vol-	VOL –	Vol-
OK	OK	OK	OK
V+ ▶	Right	▶	Right
V+ ▶	Vol+	+ VOL	Vol+
CH-/▼	CH-	CH PAGE –	CH- / Page-

Originalfernbedienung		Ersatzfernbedienung	
CH-/▼	Down	▼	Down
FILELIST	Filelist	LIST SMART	Smart / List
REC	Rec	REC MODE	Rec / Rec Mode
■	Stop	HOLD ■	Stop / Hold
▶II	Play	SLOW ▶	Play / Slow
▶II	Pause	STEP-FREEZE II	Pause / Step / Freeze
FAV.	<<	TUNE- ◀◀	<< / Tune-
DEL.	>>	TUNE+ ▶▶	>> / Tune+
MOVE	I<<	PRESET- ⏮	I<< / Preset-
LOCK	>>I	PRESET+ ⏭	>>I / Preset+
DAILY	Red/FAV/Daily	NETFLIX SEARCH	Red / Netflix / Search
WEEKLY	Green/DEL/Weekl	APP REPEAT	Green / APP / Repeat
P.INFO	Yellow/Movie/P.Inf	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TIMER	Blue/Look/Timer	Prime Video RANDOM	Blue / Prime Video / Random

Originalfernbedienung	Ersatzfernbedienung