Mandis shop

LG COV33552401

Originalfernbedienung		Ersatzfernbedienung	
	Power		Power
	Open/Close	SURROUND	Eject / Surround
	Vol +	VOL	Vol +
	F	OPT-TOOLS SETUP	Setup / OPT /
	Preset/Folder Up	CH PAGE	CH+ / Page+
	Vol -	VOL	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer
	Preset/Folder	CH PAGE	CH- / Page-
PROGRAM /MEMORY	Program/Memory	LIST SMART	Smart / List
DISPLAY MODE	Display Mode	MEDIA DISPLAY	Display / Media
DELETE	Delete	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SOUND EFFECT	Sound Effect	LANG I/II AUDIO	Audio / Lang I/II
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
INFO	Info	ANGLE INFO	Info / Angle
TUNING –	I<<</Tuning-	PRESET-	I<< / Preset-
▶/II	Play	SLOW	Play / Slow
▶/II	Pause	STEP-FREEZE	Pause / Step / Freeze

Originalfernbedienung		Ersatzfernbedienung	
TUNING +	Tuning+/>>I	PRESET+	>>I / Preset+
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
■	Stop	HOLD	Stop / Hold
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
CLOCK	Clock	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
ALARM	Alarm	OK	OK
USB REC	USB Rec	REC MODE	Rec / Rec Mode
RDS/SET	RDS/Set	HOME MENU	Menu / Home
PTY	PTY	SIZE ZOOM	Zoom / Size
*	*		Down

https://alleferbedienungen.de/LG-10721-534-ersatzfernbedienung-fur-LG-COV33552401.htm