Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Source	AV / Input / RDS	Left	Left
Power	Power	Right	Right
blank	Eject / Surround	OK	OK
[>|<]	Pause / Step / Freeze	Down	Down
square	Info / Angle	Menu	Menu / Home
Red / Rec / Movi	Rec / Rec Mode	V +	Vol +
Red / Rec / Movi	Red / Netflix / Search	P +	CH+ / Page+
Green / << /	<< / Tune-	V -	Vol -
Green / << /	Green / APP / Repeat	Mute	Mute / Dimmer
Yellow / Stop / Child	Stop / Hold	P -	CH- / Page-
Yellow / Stop / Child	Yellow / YouTube / Repeat	1	1
Blue / Play / Ne	Blue / Prime Video / Random	2	2
Blue / Play / Ne	Play / Slow	3	3
>> / Other	>> / Tune+	4	4
Guide	Guide / EPG / -/--	5	5
Up	Up	6	6
Text	Text / Goto	7	7

Originalfernbedienung	Ersatzfernbedienung
8	USB 8
9	BLUETOOTH 9
i +	SHIFT + ANGLE INFO (Shift + Info / Angle)
0	HDMI - SAT 0
P < P / -/--	RETURN BACK (Back / Return)
Smart Sound	TITLE SOUND (Sound / Title)
Active Control	LIST SMART (Smart / List)
Smart Picture	FORMAT PICTURE (Picture / Format)
Timer	TIMER SLEEP (Sleep / Timer)
[?]	EQ SUBTITLE (Subtitle / EQ)
Zoom	SIZE ZOOM (Zoom / Size)
[1|2]	OPT-TOOLS SETUP (Setup / OPT /)
[<|>]	TOP MENU D.MENU (D. Menu / Top)
[|]	PROGRAM TV/RADIO (TV/Radio /)
small squares	MEDIA DISPLAY (Display / Media)
I-II	LANG I/II AUDIO (Audio / Lang I/II)
Instant Rec	SHIFT + REC MODE (Shift + Rec / Rec Mode)

Originalfernbedienung	Ersatzfernbedienung
Format	SHIFT + FORMAT PICTURE (Shift + Picture / Format)
DNR	PC FAV MARKER (Fav / Marker / PC)
Instant Stop	SHIFT + HOLD ■ (Shift + Stop /)

Originalfernbedienung	Ersatzfernbedienung
Power	Power
Rec	Rec / Rec Mode
<<	<< / Tune-
<<	I << / Preset-
Stop	Stop / Hold
Play	Play / Slow
>>	>> / Tune+
>>	>>I / Preset+
Up	Up
Text	Text / Goto
Left	Left
Right	Right
OK	OK
Down	Down
Menu	Menu / Home
P +	CH+ / Page+
P-	CH- / Page-

Originalfernbedienung	Ersatzfernbedienung
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
i +	Info / Angle
0	0
P < P / -/--	Back / Return
Timer	Sleep / Timer
[?]	Smart / List
Zoom	Zoom / Size
I / II	Audio / Lang I/II