Originalfernbedienung		Ersatzfernbedienung	
	Power		Power
	Source		AV / Input / RDS
	HDMI		Shift + 0
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	--		Zoom / Size
	PRE-CH		Fav / Marker / PC
	Vol +		Vol +
	Vol -		Vol -

Originalfernbedienung		Ersatzfernbedienung	
	Mute		Mute / Dimmer
	CH List		Shift + Smart / List
	Smart Hub		Smart / List
	Menu		Menu / Home
	Guide		Guide / EPG / -/--
	Tools		Setup / OPT /
	Info		Info / Angle
	Return		Back / Return
	Exit		Exit / Cancel / Clear
	Up		Up
	Enter		OK
	Down		Down
	Right		Right
	Left		Left
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
D	Blue	Prime Video / RANDOM	Blue / Prime Video / Random		
Family Story	Family Story	GOTO TEXT	Text / Goto		
SEARCH	Search	SHIFT +	NETFLIX / SEARCH — Shift + Red / Netflix /		
MTS	MTS	EQ SUBTITLE	Subtitle / EQ		
P.SIZE	P. Size	FORMAT PICTURE	Picture / Format		
SUPPORT	Support	LANG I/II AUDIO	Audio / Lang I/II		
CC	CC	PROGRAM TV/ RADIO	TV/ Radio /		
<<	<<	TUNE- <<	<< / Tune-		
Pause	Pause	STEP-FREEZE	Pause / Step / Freeze		
>>	>>	TUNE+ >>	>> / Tune+		
Rec	Rec	REC MODE	Rec / Rec Mode		
Play	Play	SLOW	Play / Slow		
Stop	Stop	HOLD	Stop / Hold		
CH+	CH+	CH PAGE +	CH+ / Page+		
CH-	CH-	CH PAGE −	CH- / Page-		