Originalfernbedienung		Ersatzfernbedienung	
DISPLAY	Display	MEDIA DISPLAY	Display / Media
EJECT	Eject	SURROUND	Eject / Surround
ON/STANDBY	On/Standby		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
CH	CH+	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CH	CH-	CH PAGE –	CH- / Page-
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TRK	TRK Up	+ VOL	Vol+
I.SELECT	I.Select	YouTube REPEAT A-B	Yellow / YouTube / Repeat
0	0	HDMI - SAT 0	0

Originalfernbedienung		Ersatzfernbedienung	
COUNT.RST	Count.RST	NETFLIX SEARCH	Red / Netflix / Search
TRK	TRK Down	VOL –	Vol-
F.ADV	F.ADV	GOTO TEXT	Text / Goto
INDEX	Index	ANGLE INFO	Info / Angle
COUNT/TR	Count.TR	APP REPEAT	Green / APP / Repeat
CLR/RST	CLR/RST	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MENU	Menu	HOME MENU	Menu / Home
REC	Rec	REC MODE	Rec / Rec Mode
TIMER	Timer Rec	TIMER SLEEP	Sleep / Timer
PLAY	Play/Up	SLOW	Play / Slow
PLAY	Play/Up		Up
REW	<<</Left		Left
REW	<<</Left	TUNE-	<< / Tune-
FF	>>/Right		Right
FF	>>/Right	TUNE+	>> / Tune+
SLOW	I>/Slow	SHIFT + SLOW	Shift + Play /
STOP	Stop/Down	HOLD	Stop / Hold

Originalfernbedienung		Ersatzfernbedienung	
STOP	Stop/Down	▼	Down
PAUSE/STILL OK	Pause/Still/OK	STEP-FREEZE	Pause / Step / Freeze
PAUSE/STILL OK	Pause/Still/OK	OK	OK
SP/LP	SP/LP	OPT-TOOLS SETUP	Setup / OPT /
PROG.	Prog.	PROGRAM TV/RADIO	TV/Radio /
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
TV/VIDEO	Tv/Video	LIST SMART	Smart / List
A.DUB	A.Dub	TITLE SOUND	Sound / Title
SAT.MONI.	SAT/Moni.	TOP MENU D.MENU	D.Menu / Top
SAT.CONT.	Cont.Sat.	SIZE ZOOM	Zoom / Size
PICTURE	Picture	FORMAT PICTURE	Picture / Format

Originalfernbedienung	Ersatzfernbedienung