Original		Replacement	
	Power		Power
	My Apps	APP MEDIA	Media
	TV/Radio	SEARCH TV/R	TV/R
1	1	1	1
2 abc	2	2	2
3 def	3	3	3
4 ghi	4	4	4
5 jkl	5	5	5
6 mno	6	6	6
7 pqrs	7	7	7
8 tuv	8	8	8
9 wxyz	9	9	9
0	0	0	0
LIST	List	DISC NAV LIST	List
Q.VIEW	Q.View	PICTURE FORMAT	Format
INPUT	Input	TIMER AV	AV
SUBTITLE Q.MENU	Q.Menu/Subtitle	AD SUBT	Subt

Original		Replacement	
GUIDE	Guide	GUIDE	Guide
INFO	Info	DISPLAY INFO	Info
MUTE	Mute	MUTE	Mute
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
P PAGE	Page+	+ CH	Ch +
P PAGE	Page-	CH −	Ch -
TEXT	Text	REPEAT TEXT	Text
T.OPT	T.Opt	SETTINGS OPT	Options
SMART	Smart	HOME SMART	Smart
FAV	FAV	FAV PRE-CH	Pre Ch
BACK	Back	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
OK	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right

Original		Replacement		Original	Replacement
	Left		Left		
	Red	A	Red		
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		
LIVE TV	Stop/Line TV		Stop		
REC/*	Rec/*	REC MODE	Rec		
	Play	PLAY MODE	Play		
	Pause		Pause		
	>>		>>		
	<<		<<		
APP/*	APP/*	SHIFT + APP MEDIA	Shift + Media		
AD	AD	SHIFT + AD SUBT	Shift + Subt		
SETTINGS	Settings	SHIFT + SETTINGS OPT	Shift + Options		