Original		Replacement	
	Power		Power
SOURCE	Source	TIMER AV	AV
SUBT.	Subt.	AD SUBT	Subt
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	SHIFT + -/-- GUIDE	Shift + Guide
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
HDMI	HDMI	HOME SMART	Smart

Original		Replacement	
DTV	DTV	SEARCH TV/R	TV/R
+	Vol+	+ VOL	Vol +
–	Vol-	VOL –	Vol -
MUTE	Mute	MUTE	Mute
P	PR+	+ CH	Ch +
P	PR-	CH –	Ch -
CH LIST	CH.List	DISC NAV LIST	List
MENU	Menu	TOP MENU MENU	Menu
	Media.P	APP MEDIA	Media
GUIDE	Guide	-/-- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
⏎	Enter	OK	Ok

Original		Replacement	
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
A	Red/A	A	Red
B	Green/B	B	Green
C	Yellow/C	C	Yellow
D	Blue/D	D	Blue
PIP	PIP	ECO 3D	3D
P ∨	PIP Down	⏮	I<<
P ∧	PIP Up	⏭	>>I
P.MODE	P.Mode	SHIFT + PICTURE FORMAT	Shift + Format
SRS	SRS	SOUND DUAL	Dual
P.SIZE	P.Size	PICTURE FORMAT	Format
STILL	Still	E-MANUAL D.MENU	D. Menu
●	Rec	REC MODE ●	Rec
■	Stop	■	Stop
◀◀	<<	⏪	<<
▶II	Play	PLAY MODE ▶	Play

Original		Replacement	
▶II	Pause	II	Pause
▶▶	>>	⏩	>>