Original		Replacement	
	Power		Power
PORTAL	Portal/Energy Saving	TIMER SLEEP	Sleep / Timer
RATIO	[ ]/Ratio	FORMAT PICTURE	Picture / Format
INPUT	Input	RDS AV INPUT	AV / Input / RDS
TV	TV	PROGRAM TV/ RADIO	TV/Radio /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	List	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0
Q.VIEW	Q.View	TOP MENU D.MENU	D.Menu / Top Menu

Original		Replacement	
+	Vol+	+ VOL	Vol+
FAV	Fav	PC FAV MARKER	Fav / Marker / PC
P	PR+/Page Up	+ CH PAGE	CH+ / Page+
–	Vol-	VOL –	Vol-
3D	3D	SIZE ZOOM	Zoom / Size
P	PR-/Page Down	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
SETTINGS	Settings	OPT-TOOLS SETUP	Setup / OPT /
	Info/Home	ANGLE INFO	Info / Angle
3D OPTION Q.MENU	Q.Menu/3D	HOME MENU	Menu / Home
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
BACK	Back	RETURN BACK	Back / Return
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement		Original	Replacement
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
TEXT	Text	GOTO TEXT	Text / Goto		
T.OPT	T.Opt	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
	Stop	HOLD	Stop / Hold		
	Play	SLOW	Play / Slow		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	<<	TUNE-	<< / Tune-		
	>>	TUNE+	>> / Tune+		
SIMPLINK	Simplink	MEDIA DISPLAY	Display / Media		
AD	AD	LANG I/II AUDIO	Audio / Lang I/II		
REC	Rec	REC MODE	Rec / Rec Mode		
MY APPS	My APPS	SHIFT + APP REPEAT	Shift + Green / APP / Repeat		