Original		Replacement	
	Tv	PROGRAM TV/RADIO	TV/Radio /
	Power		Power
	World	LIST SMART	Smart / List
	[≡]/Text	GOTO TEXT	Text / Goto
	Sleep	TIMER SLEEP	Sleep / Timer
	Music/Movie/Phot	TITLE SOUND	Sound / Title
1	1	TV 1	1
2 ABC	2	DVD 2	2
3 DEF	3	CD-STB 3	3
4 GHI	4	VIDEO 4	4
5 JKL	5	TAPE 5	5
6 MNO	6	TUNER 6	6
7 PQRS	7	AUX-HDD 7	7
8 TUV	8	USB 8	8
9 WXYZ	9	BLUETOOTH 9	9
SOURCE	Source/Games	RDS AV INPUT	AV / Input / RDS
0	0	HDMI-SAT 0	0

Original		Replacement	
	Recall	SHIFT + RETURN BACK	Shift + Back / Return
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
V	Vol +	+ VOL	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
P	PR+	+ CH PAGE	CH+ / Page+
V	Vol -	VOL −	Vol -
i	i	ANGLE INFO	Info / Angle
P	PR-	CH PAGE −	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
Q. MENU	Q. Menu	TOP MENU D.MENU	D. Menu / Top
	Left		Left
OK	OK	OK	OK
	Right		Right

Original		Replacement		Original	Replacement
BACK	Back	RETURN BACK	Back / Return		
	Down		Down		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
	[≡] . .	OPT-TOOLS SETUP	Setup / OPT /		
LANG	Lang	LANG I/II AUDIO	Audio / Lang I/II		
	Q/ *	SIZE ZOOM	Zoom / Size		
	Q. . / *	FORMAT PICTURE	Picture / Format		
	Play	SLOW	Play / Slow		
	Stop	HOLD	Stop / Hold		
	<<	TUNE-	<< / Tune-		
	>>	TUNE+	>> / Tune+		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	Rec	REC MODE	Rec / Rec Mode		
	Guide	-/-- GUIDE EPG	Guide / EPG / -/--		
	[- O-]	MEDIA DISPLAY	Display / Media		