Mandis shop

RE91141

Original		Replacement	
	Power		Power
	Mute		Mute
	Moon	1 SETUP	1 / Setup
TV ARC	Tv Arc.	4 MODE	4 / Mode
OPT	Opt:	7 REP	7 / Rep
AUX	AUX	SRC	Source
	Vol +	V+	V+
	Vol -	V-	V-
BASS	Bass+		+
BASS	Bass-		-
VOICE	Voice+		Up
VOICE	Voice-		Down
	Play	BAND	Play / Band
	I<	EQ	I<
	>I	CLEAR	>I
	Videocamara	9 DISP	9 / Disp
	Playing	8 A-B	8 / A-B

Original		Replacement	
	♫	5 AUDIO	5 / Audio

https://alle-fernbedienungen.de/1084-886-replacement-remote-control-for-Polk-RE91141.htm