Original		Replacement	
POWER	Power		Power
INPUT TV	Tv Input	SHIFT + TIMER AV	Shift + AV
INPUT	Input	TIMER AV	AV
RATIO	Ratio	HOME SMART	Smart
- ☼		SHIFT + ◄	Shift + Left
☼ +		SHIFT + ►	Shift + Right
SIMPLINK	Simplink	APP MEDIA	Media
SLEEP	Sleep	PROG SLEEP	Sleep
TEXT	Text	REPEAT TEXT	Text
I/II	I/II	SOUND DUAL	Dual
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	Stop	■	Stop
	Play	PLAY MODE ►	Play
	Pause	❚❚	Pause

Original		Replacement	
	I <<		I <<
	<<		<<
	>>		>>
	>>I		>>I
EXIT	Exit	CLEAR EXIT	Exit
LIST	List	DISC NAV LIST	List
MENU	Menu	TOP MENU MENU	Menu
Q.VIEW	Q. View	SETTINGS OPT	Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
FAV	FAV	FAV PRE-CH	Pre Ch
MUTE	Mute	MUTE	Mute

Original		Replacement	
PR+	PR+	CH	Ch +
PR-	PR-	CH	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TIME	[≡o] / Time	GUIDE	Guide
HOLD	[≡+] / Hold	SUBT	Subt
SIZE	[≡♦] / Size	FORMAT	Format
UPDATE	[≡x] / Update	TV/R	TV/R
INDEX	[≡i] / Index	INFO	Info

Original		Replacement	
REVEAL	[≡?] / Reveal	3D	3D

Original		Replacement	
POWER	Power		Power
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
	<<		<<
	I <<		I <<
	>>		>>
	>>I		>>I
MENU	Menu	TOP MENU MENU	Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
1	1	1	1
2	2	2	2
3	3	3	3

Original		Replacement	
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute

Original		Replacement	
POWER	Power		Power
INPUT	Input Source	TIMER AV	AV
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
	Rec	REC MODE	Rec
	<<		<<
	>>		>>
PR +	PR+	CH +	Ch +
PR −	PR-	CH −	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7

Original		Replacement	
8	8	8	8
9	9	9	9
0	0	0	0
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute