Original	Replacement	Original	Replacement
Power	Power	ShowView	Subt
DVD	Smart	Direct Tv Rec	TV/R
1	1	I << Skip/Index	I <<
2	2	Skip/Index >>I	>>I
3	3	<< Slow/Search	<<
4	4	Slow/Search FF	>>
5	5	Stop	Stop
6	6	Pause	Pause
7	7	Play	Play
8	8	Direct Navigator/Top	Menu
9	9	Functions	Options
0	0	S/Sub Menu	D. Menu
*Cancel/Reset	Exit	Return	Back
Input Select	AV	Up	Up
Ch+Track/VLoc	Ch +	Down	Down
Ch-Track/VLock-	Ch -	Right	Right
Audio	Dual	Left	Left

Mandis shop

EUR7720KS0

Original		Replacement		Original	Replacement
ENTER	Enter	OK	Ok		
PROG/CHECK	Prog/Check	PROG SLEEP	Sleep		
DISPLAY	Display	DISPLAY INFO	Info		
STATUS	Status	B	Green		
TIME SLIP ◄◄JET REW	<< Jet Rew / Time Slip	PICTURE FORMAT	Format		
REC	Rec	REC MODE	Rec		
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec		
EXT LINK	Ext Link	APP MEDIA	Media		
TIMER	Timer	SHIFT + TIMER AV	Shift + AV		
DVD ERASE C	Dvd Erase C	D	Blue		
CREATE CHAPTER	Create Chapter	C	Yellow		