Original		Replacement	
	Power Tv		Power
	Av Tv	TIMER AV	AV
MENU	Menu Tv	TOP MENU MENU	Menu
	Up Tv		Up
	Down Tv		Down
	Left Tv		Left
	Right Tv		Right
OK	Ok Tv	OK	Ok
INFO	Info Tv	DISPLAY INFO	Info
EXIT	Exit Tv	CLEAR EXIT	Exit
	Red Tv	A	Red
	Green Tv	B	Green
	Yellow Tv	C	Yellow
	Blue Tv	D	Blue
+ VOL	Vol + Tv	+ VOL	Vol +
VOL −	Vol - Tv	VOL −	Vol -
	Mute Tv	MUTE	Mute

Original		Replacement	
P•P	Back Tv	RETURN BACK	Back
+ CH	Ch+ Tv	+ CH	Ch +
CH −	Ch- Tv	CH −	Ch -
▼P[≡]	▼P[≡] Tv		I <<
▲P[ ]	▲P[ ] Tv		>>I
	<< Tv		<<
	>> Tv		>>
	Stop Tv		Stop
	Play Tv	PLAY MODE	Play
1	1 Tv	1	1
2	2 Tv	2	2
3	3 Tv	3	3
4	4 Tv	4	4
5	5 Tv	5	5
6	6 Tv	6	6
7	7 Tv	7	7
8	8 Tv	8	8

Original	Replacement
9 Tv	9
0 Tv	0
Text Tv	Text
#Help Tv	Pre Ch
▼P [≡] Tv2	Shift + I<<
▲P [ ] Tv2	Shift + >>I
Rec Tv2	Shift + Rec
Play Tv2	Shift + Play
Av Tv2	Shift + AV
<< Tv2	Shift + <<
>> Tv2	Shift + >>
Power Tv2	Shift + Power
Guide Tv2	Shift + Guide
Menu Tv2	Shift + Menu
Up Tv2	Shift + Up
Left Tv2	Shift + Left
Right Tv2	Shift + Right

Original	Replacement
Down Tv2	Shift + Down
Ok Tv2	Shift + Ok
Info Tv2	Shift + Info
Green Tv2	Shift + Green
Red Tv2	Shift + Red
Exit Tv2	Shift + Exit
Yellow Tv2	Shift + Yellow
Blue Tv2	Shift + Blue
Back Tv2	Shift + Back
Ch+ Tv2	Shift + Ch +
Ch- Tv2	Shift + Ch -
Stop Tv2	Shift + Stop
Pause Tv2	Shift + Pause
1 Tv2	Shift + 1
2 Tv2	Shift + 2
3 Tv2	Shift + 3
4 Tv2	Shift + 4

Original		Replacement		Original	Replacement
5	5 Tv2	SHIFT + 5	Shift + 5		
6	6 Tv2	SHIFT + 6	Shift + 6		
7	7 Tv2	SHIFT + 7	Shift + 7		
8	8 Tv2	SHIFT + 8	Shift + 8		
9	9 Tv2	SHIFT + 9	Shift + 9		
0	0 Tv2	SHIFT + 0	Shift + 0		
* TXT	Text Tv2	SHIFT + REPEAT TEXT	Shift + Text		
# HELP	#Help Tv2	SHIFT + FAV PRE-CH	Shift + Pre Ch		

Original	Replacement
Power DVD	Power
AV DVD/DVR	AV
Guide DVD/DVR	Guide
Menu DVD/DVR	Menu
Info DVD/DVR	Info
Exit DVD/DVR	Exit
Up DVD/DVR	Up
Down DVD/DVR	Down
Left DVD/DVR	Left
Right DVD/DVR	Right
Ok DVD/DVR	Ok
Red DVD/DVR	Red
Green DVD/DVR	Green
Yellow	Yellow
Blue DVD/DVR	Blue
Vol + DVD/DVR	Vol +
Vol - DVD/DVR	Vol -

Original	Replacement
Mute DVD/DVR	Mute
Back DVD/DVR	Back
Ch+ DVD/DVR	Ch +
▼P[≡] DVD/DVR	I <<
Ch- DVD/DVR	Ch -
▲P[ ] DVD/DVR	>>I
<< DVD/DVR	<<
>> DVD/DVR	>>
Play DVD/DVR	Play
Pause DVD/DVR	Pause
Stop DVD/DVR	Stop
Rec DVD/DVR	Rec
1 DVD/DVR	1
2 DVD/DVR	2
3 DVD/DVR	3
4 DVD/DVR	4
5 DVD/DVR	5

Original		Replacement		Original	Replacement
6	6 DVD/DVR	6	6		
7	7 DVD/DVR	7	7		
8	8 DVD/DVR	8	8		
9	9 DVD/DVR	9	9		
0	0 DVD/DVR	0	0		
* TXT	Text DVD/DVR	REPEAT TEXT	Text		
# HELP	#Help DVD/DVR	FAV PRE-CH	Pre Ch		
⏻	Power DVR	SHIFT + ⏻	Shift + Power		

Original		Replacement		Original		Replacement	
	Power		Power		Mute	MUTE	Mute
MENU	Menu	TOP MENU MENU	Menu		Back	RETURN BACK	Back
GUIDE	Guide	GUIDE	Guide	+ CH	Ch+ SAT/CABLE	+ CH	Ch +
AV	AV SAT/CABLE	TIMER AV	AV	CH −	Ch- SAT/CABLE	CH −	Ch -
	Up SAT/CABLE		Up		<< SAT/CABLE		<<
	Down		Down		>> SAT/CABLE		>>
	Left SAT/CABLE		Left		Stop SAT/CABLE		Stop
	Right		Right		Rec SAT/CABLE	REC MODE	Rec
OK	Ok SAT/CABLE	OK	Ok		Play SAT/CABLE	PLAY MODE	Play
INFO	Info SAT/CABLE	DISPLAY INFO	Info		Pause		Pause
EXIT	Exit SAT/CABLE	CLEAR EXIT	Exit	1	1 SAT/CABLE	1	1
	Red SAT/CABLE	A	Red	2	2 SAT/CABLE	2	2
	Green	B	Green	3	3 SAT/CABLE	3	3
	Yellow SAT/CABLE	C	Yellow	4	4 SAT/CABLE	4	4
	Blue SAT/CABLE	D	Blue	5	5 SAT/CABLE	5	5
+ VOL	Vol +	+ VOL	Vol +	6	6 SAT/CABLE	6	6
VOL −	Vol - SAT/CABLE	VOL −	Vol -	7	7 SAT/CABLE	7	7

Original		Replacement		Original	Replacement
8	8 SAT/ CABLE	8	8		
9	9 SAT/ CABLE	9	9		
0	0 SAT/ CABLE	0	0		
# HELP	#Help	FAV PRE-CH	Pre Ch		
* TXT	Text SAT/ CABLE	REPEAT TEXT	Text		

Original	Replacement	Original	Replacement
Power DVBT	Power	Ch+ DVBT	Ch +
Guide DVBT	Guide	Ch- DVBT	Ch -
Menu DVBT	Menu	Pause DVBT	Pause
Up DVBT	Up	1 DVBT	1
Down DVBT	Down	2 DVBT	2
Left DVBT	Left	3 DVBT	3
Right DVBT	Right	4 DVBT	4
Ok DVBT	Ok	5 DVBT	5
Info DVBT	Info	6 DVBT	6
Red DVBT	Red	7 DVBT	7
Green DVBT	Green	8 DVBT	8
Yellow DVBT	Yellow	9 DVBT	9
Blue DVBT	Blue	0 DVBT	0
Vol + DVBT	Vol +	Power VCR	Shift + Power
Vol - DVBT	Vol -	Av VCR	AV
Mute DVBT	Mute	<< VCR	<<
Back DVBT	Back	Stop VCR	Stop

Original		Replacement	
	>> VCR		>>
	Play VCR	PLAY MODE	Play
	Rec VCR	REC MODE	Rec
	Pause VCR	SHIFT +	Shift + Pause
GUIDE	Guide VCR	SHIFT + GUIDE	Shift + Guide
MENU	Menu VCR	SHIFT + TOP MENU MENU	Shift + Menu
	Up VCR	SHIFT +	Shift + Up
	Down VCR	SHIFT +	Shift + Down
	Left VCR	SHIFT +	Shift + Left
	Right VCR	SHIFT +	Shift + Right
OK	Ok VCR	SHIFT + OK	Shift + Ok
INFO	Info VCR	SHIFT + DISPLAY INFO	Shift + Info
EXIT	Exit VCR	CLEAR EXIT	Exit
	Red VCR	SHIFT + A	Shift + Red
	Green VCR	SHIFT + B	Shift + Green
	Yellow VCR	SHIFT + C	Shift + Yellow
	Blue VCR	SHIFT + D	Shift + Blue

Original		Replacement	
P-P	Back VCR	SHIFT + RETURN BACK	Shift + Back
+ CH	Ch+ VCR	SHIFT + + CH	Shift + Ch +
CH −	Ch- VCR	SHIFT + CH −	Shift + Ch -
1	1 VCR	SHIFT + 1	Shift + 1
2	2 VCR	SHIFT + 2	Shift + 2
3	3 VCR	SHIFT + 3	Shift + 3
4	4 VCR	SHIFT + 4	Shift + 4
5	5 VCR	SHIFT + 5	Shift + 5
6	6 VCR	SHIFT + 6	Shift + 6
7	7 VCR	SHIFT + 7	Shift + 7
8	8 VCR	SHIFT + 8	Shift + 8
9	9 VCR	SHIFT + 9	Shift + 9
0	0 VCR	SHIFT + 0	Shift + 0
* TXT	Text VCR	REPEAT TEXT	Text
# HELP	#Help VCR	FAV PRE-CH	Pre Ch