Original		Replacement	
	Power Tuner		Power
	Mute	MUTE	Mute
	1 Tuner	1	1
	2 Tuner	2	2
	3 Tuner	3	3
	4 Tuner	4	4
	5 Tuner	5	5
	6 Tuner	6	6
	7 Tuner	7	7
	8 Tuner	8	8
	9 Tuner	9	9
	0 Tuner	0	0
CINEMA GO	Cinema Go	GUIDE	Guide
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -
	Play Tuner / Phono/ Cabl	PLAY MODE	Play
	Stop Tuner / Phono/ Cabl e Box		Stop

Original		Replacement	
LOUDNESS	Loudness	AD SUBT	Subt
SUBW. ON/OFF	Subw. On/Off	HOME SMART	Smart
VIRTUAL MODE	Mode/Virtual	SETTINGS OPT	Options
NIGHT	Night	ECO 3D	3D
SURROUND ON/OFF	Surround On/Off	APP MEDIA	Media
REAR +	Channel / Rear +	+ CH	Ch +
CHANNEL −	Channel / Rear -	CH −	Ch -
SURROUND MODE	Surround Mode	SEARCH TV/R	TV/R
TEST TONE	Test Tone	CLEAR EXIT	Exit
SUB WOOFER +	Sub woofer +	B	Green
SUB WOOFER −	Sub Woofer -	A	Red
	Right Tuner		Right
	Up Tuner		Up
	Down Tuner		Down
	Left Tuner		Left
OK	OK Tuner	OK	Ok
GUIDE MENU	Menu / Guide	TOP MENU MENU	Menu

Tuner

Original		Replacement		Original	Replacement
NEWS/TA	i / News/ TA	DISPLAY INFO	Info		
CHANNE	I < Channel / Track		I <<		
L/TRACK	Channel / Track >I Tuner		>>I		
FR.D.	Pause/ FR. D.		Pause		
TUNER	Tuner	SHIFT + HOME SMART	Shift + Smart		
PHONO	Phono	SHIFT + APP MEDIA	Shift + Media		
	Power Phono	SHIFT +	Shift + Power		

Original		Replacement	
	Power Tv		Power
TV	TV	D	Blue
MUTE	Mute Tv	MUTE	Mute
1	1 Tv	1	1
2	2 Tv	2	2
3	3 Tv	3	3
4	4 Tv	4	4
5	5 Tv	5	5
6	6 Tv	6	6
7	7 Tv	7	7
8	8 Tv	8	8
9	9 Tv	9	9
0	0 Tv	0	0
GUIDE MENU	Menu/Guide Tv	TOP MENU MENU	Menu
OK	OK Tv	OK	Ok
	Up Tv		Up
	Down Tv		Down

Original		Replacement	
	Right Tv		Right
	Left Tv		Left
+	Vol + Tv/CD	+ VOL	Vol +
−	Vol - Tv/CD	VOL −	Vol -
	Play Tv	PLAY MODE	Play
	Stop Tv		Stop
i NEWS/TA	i/News/TA Tv	DISPLAY INFO	Info
CHANNE	I< Channel/Track		I<<
L/TRACK	Channel/Track >I		>>I
	Power CD	SHIFT +	Shift + Power
CD	CD	C	Yellow
MUTE	Mute CD	SHIFT + MUTE	Shift + Mute
1	1 CD	SHIFT + 1	Shift + 1
2	2 CD	SHIFT + 2	Shift + 2
3	3 CD	SHIFT + 3	Shift + 3
4	4 CD	SHIFT + 4	Shift + 4
5	5 CD	SHIFT + 5	Shift + 5

Original		Replacement		Original	Replacement
6	6 CD	SHIFT + 6	Shift + 6		
7	7 CD	SHIFT + 7	Shift + 7		
8	8 CD	SHIFT + 8	Shift + 8		
9	9 CD	SHIFT + 9	Shift + 9		
0	0 CD	SHIFT + 0	Shift + 0		
	Up CD	SHIFT + ▲	Shift + Up		
	Down CD	SHIFT + ▼	Shift + Down		
	Right CD	SHIFT + ▶	Shift + Right		
	Left CD	SHIFT + ◀	Shift + Left		
i NEWS/TA	i / News/TA CD	SHIFT + DISPLAY INFO	Shift + Info		
■	Stop CD	SHIFT + ■	Shift + Stop		
▶	Play CD	SHIFT + PLAY MODE ▶	Shift + Play		
CHANNE ⏮	I < CD	«	<<		
E/TRACK ⏭	>I CD	»	>>		
FR.D. ⏸	Pause/FR. D. CD	⏸	Pause		
CANCEL	: >/Cancel CD	CLEAR EXIT	Exit		
DVD DISC	Disc/DVD CD	HOME SMART	Smart		

Original		Replacement	
	Power SAT		Power
SAT	SAT	C	Yellow
1	1 SAT	1	1
2	2 SAT	2	2
3	3 SAT	3	3
4	4 SAT	4	4
5	5 SAT	5	5
6	6 SAT	6	6
7	7 SAT	7	7
8	8 SAT	8	8
9	9 SAT	9	9
0	0 SAT	0	0
MUTE	Mute SAT	MUTE	Mute
+	Vol + SAT/DVD	+ VOL	Vol +
–	Vol - SAT/DVD	VOL –	Vol -
	Play SAT	PLAY MODE	Play
	Stop SAT		Stop

Original		Replacement	
NEWS/TA	i/News/TA SAT	DISPLAY INFO	Info
GUIDE MENU	Menu/Guide	TOP MENU MENU	Menu
OK	OK SAT	OK	Ok
	Up SAT		Up
	Down SAT		Down
	Right SAT		Right
	Left SAT		Left
CHANNE	I< Channel/Track SAT		I<<
L/TRACK	Channel/Track >I SAT		>>I
CANCEL	:>/Cancel SAT	CLEAR EXIT	Exit
INDEX T·C	T·C/Index SAT	RETURN BACK	Back
	Power DVD	SHIFT +	Shift + Power
DVD	DVD	D	Blue
1	1 DVD	SHIFT + 1	Shift + 1
2	2 DVD	SHIFT + 2	Shift + 2
3	3 DVD	SHIFT + 3	Shift + 3
4	4 DVD	SHIFT + 4	Shift + 4

Original		Replacement		Original		Replacement	
5	5 DVD	SHIFT + 5	Shift + 5	DVD DISC	Disc DVD	HOME SMART	Smart
6	6 DVD	SHIFT + 6	Shift + 6	REC AUDIO	Audio DVD	SOUND DUAL	Dual
7	7 DVD	SHIFT + 7	Shift + 7	CANCEL	:>/ Cancel DVD	SHIFT + CLEAR EXIT	Shift + Exit
8	8 DVD	SHIFT + 8	Shift + 8	FR.D.	Pause/ FR. D.	II	Pause
9	9 DVD	SHIFT + 9	Shift + 9	INDEX T-C	T· C/ Index DVD	SHIFT + RETURN BACK	Shift + Back
0	0 DVD	SHIFT + 0	Shift + 0				
GUIDE MENU	Menu/ Guide	SHIFT + TOP MENU MENU	Shift + Menu				
OK	OK DVD	SHIFT + OK	Shift + Ok				
	Up DVD	SHIFT + ▲	Shift + Up				
	Down DVD	SHIFT + ▼	Shift + Down				
	Right DVD	SHIFT + ▶	Shift + Right				
	Left DVD	SHIFT + ◀	Shift + Left				
▶	Play DVD	SHIFT + PLAY MODE ▶	Shift + Play				
■	Stop DVD	SHIFT + ■	Shift + Stop				
i NEWS/TA	i / News/ TA DVD	SHIFT + DISPLAY INFO	Shift + Info				
CHANNE	I<	Channel / Track DVD	«	<<			
E/TRACK >I	Channel / Track >I DVD	»	>>				

Original		Replacement	
	Power VCR		Power
VCR	VCR	C	Yellow
MUTE	Mute VCR	MUTE	Mute
1	1 VCR	1	1
2	2 VCR	2	2
3	3 VCR	3	3
4	4 VCR	4	4
5	5 VCR	5	5
6	6 VCR	6	6
7	7 VCR	7	7
8	8 VCR	8	8
9	9 VCR	9	9
0	0 VCR	0	0
GUIDE MENU	Menu/Guide	TOP MENU MENU	Menu
	Up VCR		Up
OK	OK VCR	OK	Ok
	Down VCR		Down

Original		Replacement	
	Right VCR		Right
	Left VCR		Left
	Vol + VCR	+ VOL	Vol +
	Vol - VCR	VOL −	Vol -
	Play VCR	PLAY MODE	Play
	Stop VCR		Stop
CHANNE	I< Channel/Track VCR		I <<
L/TRACK	Channel/Track >I VCR		>>I
REC AUDIO	Rec VCR	REC MODE	Rec
CANCEL	:>/Cancel VCR	CLEAR EXIT	Exit
FR.D.	Pause/FR.D VCR		Pause
INDEX T-C	T·C/Index VCR	RETURN BACK	Back
	Power	SHIFT +	Shift + Power
CDR/TAPE	CDR/Tape	D	Blue
1	1 CDR/Tape	SHIFT + 1	Shift + 1
2	2 CDR/Tape	SHIFT + 2	Shift + 2
3	3 CDR/Tape	SHIFT + 3	Shift + 3

Original	Replacement
4 CDR/Tape	SHIFT + 4 — Shift + 4
5 CDR/Tape	SHIFT + 5 — Shift + 5
6 CDR/Tape	SHIFT + 6 — Shift + 6
7 CDR/Tape	SHIFT + 7 — Shift + 7
8 CDR/Tape	SHIFT + 8 — Shift + 8
9 CDR/Tape	SHIFT + 9 — Shift + 9
0 CDR/Tape	SHIFT + 0 — Shift + 0
Up CDR/Tape	SHIFT + ▲ — Shift + Up
Down CDR/Tape	SHIFT + ▼ — Shift + Down
Right CDR/Tape	SHIFT + ▶ — Shift + Right
Left CDR/Tape	SHIFT + ◀ — Shift + Left
i / News/TA	DISPLAY INFO — Info
I< Channel / Track CDR/Tape	SHIFT + I<< — Shift + I<<
Channel / Track >I CDR/Tape	SHIFT + >>I — Shift + >>I
Rec CDR/Tape	SHIFT + REC MODE — Shift + Rec
: >/ Cancel	SHIFT + CLEAR EXIT — Shift + Exit
Pause/FR. D. CDR/Tape	SHIFT + II — Shift + Pause

Original	Replacement
DVD DISC — Disc CDR/Tape	HOME SMART — Smart