Original		Replacement	
STANDBY	Standby		Power
1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
0	0	0	0
P.P	P. P	RETURN BACK	Back
DTV EPG FAV	FAV	FAV PRE-CH	Pre Ch
DTV EPG FAV	DTV EPG	-/-- GUIDE	Guide
INPUT	Input	TIMER AV	AV
MUTE	Mute	MUTE	Mute
AUDIO	Audio	SOUND DUAL	Dual

Original		Replacement	
SOUND	Red/ Sound	A	Red
PICTURE	Green/ Picture	B	Green
VGA	Yellow/ VGA	C	Yellow
TV	Blue/ TV	D	Blue
HOLD	[≡+] / Hold	SETTINGS OPT	Options
REVEAL	[≡?] / Reveal	SEARCH TV/R	TV/ R
SIZE	[≡♦] / Size	PICTURE FORMAT	Format
MIX	[/ ≡]	HOME SMART	Smart
INDEX	[≡i] / Index	SHIFT + DISPLAY INFO	Shift + Info
SUB PAGE	[O] / Subpage	APP MEDIA	Media
TEXT	[≡] / Text	REPEAT TEXT	Text
VOL ▲	Vol +	+ VOL	Vol +
▼	Vol -	VOL –	Vol -
CH ▲	CH+	+ CH	Ch +
▼	CH-	CH –	Ch -
PIP	PIP	ECO 3D	3D
WIDE	Wide	ZOOM	Eject

Original		Replacement	
INFO	Info	DISPLAY INFO	Info
SLEEP	Sleep	PROG SLEEP	Sleep
MENU	Menu	TOP MENU MENU	Menu
EXIT MENU	Exit	CLEAR EXIT	Exit
EXIT MENU	Menu DTV	E-MANUAL D.MENU	D. Menu
SUBTITLE SUBTITLE	Subtitle/Subtitl DTV	AD SUBT	Subt
CH VIEW CHLIST DTV	CH View/CHList	DISC NAV LIST	List
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
OK	OK	OK	Ok

Original	Replacement