Original	Replacement	Original	Replacement
OPEN/CLOSE — Open/Close	SURROUND — Eject / Surround	POP UP/MENU — Pop Up/Menu	LIST SMART — Smart / List
POWER — Power	Power	REV — <<	TUNE- — << / Tune-
1 — 1	TV 1 — 1	PLAY/PAUSE — Play	SLOW — Play / Slow
2 — 2	DVD 2 — 2	PLAY/PAUSE — Pause	STEP-FREEZE — Pause / Step / Freeze
3 — 3	CD-STB 3 — 3	FWD — >>	TUNE+ — >> / Tune+
4 — 4	VIDEO 4 — 4	SKIP — I <<	PRESET- — I << / Preset-
5 — 5	TAPE 5 — 5	STOP — Stop	HOLD — Stop / Hold
6 — 6	TUNER 6 — 6	SKIP — >>I	PRESET+ — >>I / Preset+
7 — 7	AUX-HDD 7 — 7	HOME — Home	HOME MENU — Menu / Home
8 — 8	USB 8 — 8	SETTING — Setting	OPT-TOOLS SETUP — Setup / OPT /
9 — 9	BLUETOOTH 9 — 9	EXIT — Exit	CLEAR EXIT CANCEL — Exit / Cancel / Clear
GOTO — Goto	GOTO TEXT — Text / Goto	STEP/SLOW — Step/Slow	SHIFT + SLOW — Shift + Play /
0 — 0	HDMI-SAT 0 — 0	STEP/SLOW — Step/Slow	SHIFT + STEP-FREEZE — Shift + Pause / Step /
Clear — Clear	SHIFT + CLEAR EXIT CANCEL — Shift + Exit / Cancel / Clear	Up — Up	Up
OSC — OSC	TITLE SOUND — Sound / Title	Left — Left	Left
TOP MENU — Top Menu	TOP MENU D.MENU — D. Menu / Top	OK — OK	OK — OK
PIP — PIP	FORMAT PICTURE — Picture / Format	Right — Right	Right

Original		Replacement		Original	Replacement
RETURN	Return	RETURN BACK	Back / Return		
▼	Down	▼	Down		
PROGRAM	Red/ Program	NETFLIX SEARCH	Red / Netflix / Search		
PROGRAM	Red/ Program	PROGRAM TV/ RADIO	TV/ Radio /		
DIGEST	Green/ Digest	APP REPEAT	Green / APP / Repeat		
ZOOM	Yellow/ Zoom	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
ZOOM	Yellow/ Zoom	SIZE ZOOM	Zoom / Size		
BOOKMARK	Blue/ Bookmark	Prime Video RANDOM	Blue / Prime Video / Random		
SUB	Sub	EQ SUBTITLE	Subtitle / EQ		
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		
2nd. AUDIO	2nd. Audio	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II		
ANGLE	Angle	ANGLE INFO	Info / Angle		
A-B	A-B	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /		
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		