| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | P+ | CH+ / Page+ |
| Source | AV / Input / RDS | Vol - | Vol - |
| 1 | 1 | P- | CH- / Page- |
| 2 | 2 | Mute | Mute / Dimmer |
| 3 | 3 | [G] | Menu / Home |
| 4 | 4 | Up | Up |
| 5 | 5 | i | Info / Angle |
| 6 | 6 | Left | Left |
| 7 | 7 | OK | OK |
| 8 | 8 | Right | Right |
| 9 | 9 | Back | Back / Return |
| Lang | Audio / Lang I/II | Down | Down |
| 0 | 0 | Exit | Exit / Cancel / Clear |
| TXT | Text / Goto | << | << / Tune- |
| Home | Smart / List | Pause | Pause / Step / Freeze |
| Home | D.Menu / Top | >> | >> / Tune+ |
| Vol + | Vol + | Rec | Rec / Rec Mode |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Play | Play / Slow | | |
| Stop | Stop / Hold | | |
| Red | Red / Netflix / Search | | |
| Green | Green / APP / Repeat | | |
| Yellow | Yellow / YouTube / Repeat | | |
| Blue | Blue / Prime Video / Random | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |