| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Source | RDS AV INPUT | AV / Input / RDS |
| 1 | 1 | TV 1 | 1 |
| 2 abc | 2 | DVD 2 | 2 |
| 3 def | 3 | CD - STB 3 | 3 |
| 4 ghi | 4 | VIDEO 4 | 4 |
| 5 jkl | 5 | TAPE 5 | 5 |
| 6 mno | 6 | TUNER 6 | 6 |
| 7 pqrs | 7 | AUX - HDD 7 | 7 |
| 8 tuv | 8 | USB 8 | 8 |
| 9 wxyz | 9 | BLUETOOTH 9 | 9 |
| LANG. | Lang | LANG I/II AUDIO | Audio / Lang I/II |
| 0 | 0 | HDMI - SAT 0 | 0 |
| TXT | TXT | GOTO TEXT | Text / Goto |
| | Home | LIST SMART | Smart / List |
| | Home | TOP MENU D.MENU | D. Menu / Top |
| + V | Vol + | + VOL | Vol + |

| Original | | Replacement | |
|---|---|---|---|
| P ^ | P+ | + CH PAGE | CH+ / Page+ |
| – V | Vol - | VOL – | Vol - |
| P v | P- | CH PAGE – | CH- / Page- |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| G | [G] | HOME MENU | Menu / Home |
| | Up | | Up |
| i | i | ANGLE INFO | Info / Angle |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| BACK | Back | RETURN BACK | Back / Return |
| | Down | | Down |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | << | TUNE- | << / Tune- |
| | Pause | STEP - FREEZE | Pause / Step / Freeze |
| | >> | TUNE+ | >> / Tune+ |
| | Rec | REC MODE | Rec / Rec Mode |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Play | SLOW Play / Slow | | |
| Stop | HOLD Stop / Hold | | |
| Red | NETFLIX SEARCH Red / Netflix / Search | | |
| Green | APP REPEAT Green / APP / Repeat | | |
| Yellow | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| Blue | Prime Video RANDOM Blue / Prime Video / Random | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |