Mandis shop

RC4390

Original	Replacement	Original	Replacement
Power	Power	P+	Ch +
Source	AV	P-	Ch -
1	1	Home	Smart
2	2	G	Guide
3	3	i	Info
4	4	Back	Back
5	5	Exit	Exit
6	6	Up	Up
7	7	Down	Down
8	8	Right	Right
9	9	Left	Left
0	0	OK	Ok
Lang	Dual	Netflix	Media
TXT	Text	YouTube	Shift + Media
Vol +	Vol +	☼1	Format
Vol -	Vol -	☼2	3D
Mute	Mute	Red	Red

Original		Replacement		Original	Replacement
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		
	<<		<<		
	Pause		Pause		
	>>		>>		
	Rec	REC MODE	Rec		
	Play	PLAY MODE	Play		
	Stop		Stop		