Mandis shop

076N0ED310

Original	Replacement
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
AV	SRC
CH/TR+	CH +
CH/TR-	CH -
Rec/OTR	Rec
Up	UP
Down	DOWN

Original	Replacement
Right	RIGHT
Left	LEFT
Enter	OK
Play/Slow	Play
Pause/Still	Pause
Stop	Stop
>>	Fast Forward
<<	Rewind
Index	INFO
Cancel	EXIT
Menu	MENU
Timer Rec	WIDE
Program	OPT+
Call	P/C / FAV
Clock/Counter	-/-- / EPG
Counter Reset	MEDIA
Zero Return	BACK

Original		Replacement		Original	Replacement
	Speed SP/LP		V-FOR		
	Tv/VCR		TV/R		
	Eject		VOD		