Mandis shop

RC5103

Original		Replacement		Original		Replacement	
	Power		Power	TITLE	Blue / Title	D	Blue
	HDMI Control	E-MANUAL D.MENU	D. Menu	1	1	1	1
RECORD	Record	REC MODE	Rec	2	2	2	2
	Play	PLAY MODE	Play	3	3	3	3
	Pause		Pause	4	4	4	4
	Stop		Stop	5	5	5	5
	I<<		I<<	6	6	6	6
	<<		<<	7	7	7	7
	>>		>>	8	8	8	8
	>>I		>>I	9	9	9	9
SCREEN	Screen	PICTURE FORMAT	Format	0	0	0	0
LANG	Lang	SOUND DUAL	Dual	TEXT	Text	REPEAT TEXT	Text
SUBTITLE	Subtitle	AD SUBT	Subt	SWAP	Swap	FAV PRE-CH	Pre Ch
	Internet	APP MEDIA	Media		Up		Up
ZOOM	Red/Zoom/↑	A	Red		Down		Down
REPEAT	Green/Repeat/↓	B	Green		Right		Right
ROOT	Yellow / Root	C	Yellow		Left		Left

Original		Replacement		Original	Replacement
OK	Ok	OK	Ok		
P/CH +	P/ Ch+	CH +	Ch +		
P/CH −	P/ Ch-	CH −	Ch -		
+	Vol +	VOL +	Vol +		
−	Vol -	VOL −	Vol -		
	Mute	MUTE	Mute		
MENU	Menu	TOP MENU MENU	Menu		
SOURCE	Source	TIMER AV	AV		
RETURN	Return	RETURN BACK	Back		
EPG	Epg	-/-- GUIDE	Guide		
INFO	Info	DISPLAY INFO	Info		
SLEEP	Sleep	PROG SLEEP	Sleep		
3D	3D	ECO 3D	3D		
SEARCH MODE	Search Mode	SEARCH TV/R	TV/ R		
	Music/ Movie/ Phot	HOME SMART	Smart		
DISPLAY	Display	SHIFT + DISPLAY INFO	Shift + Info		
PRESETS	Presets	SETTINGS OPT	Options		