Original	Replacement	Original	Replacement
Power	Power	4	4
Source	AV	5	5
Rec	Rec	6	6
Play	Play	7	7
Pause	Pause	8	8
Stop	Stop	9	9
Lang	Dual	0	0
<<	<<	Tv	TV/R
>>	>>	Recall	Pre Ch
[≡]. .	Subt	Up	Up
Red	Red	Down	Down
Green	Green	Right	Right
Yellow	Yellow	Left	Left
Blue	Blue	OK	Ok
1	1	Menu	Menu
2	2	Back	Back
3	3	Exit	Exit

Original		Replacement		Original	Replacement
Q.MENU	Q. Menu	E-MANUAL D.MENU	D. Menu		
	World	APP MEDIA	Media		
	Music/Photo/Video	HOME SMART	Smart		
★/◉	*/o	ECO 3D	3D		
★/Q	*/Q	ZOOM	Eject		
	Tv List	DISC NAV LIST	List		
	Text	REPEAT TEXT	Text		
i	i	DISPLAY INFO	Info		
	Size	PICTURE FORMAT	Format		
V+	Vol +	+ VOL	Vol +		
V-	Vol -	VOL –	Vol -		
	Mute	MUTE	Mute		
P+	P+	+ CH	Ch +		
P-	P-	CH –	Ch -		