Original		Replacement	
POWER	Power		Power
OPEN/ CLOSE	Open/Close	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLEAR	Clear	CLEAR EXIT	Exit
PLAY	Play	PLAY MODE	Play
PAUSE/STEP	Pause/Step		Pause
STOP	Stop		Stop
SCAN	>>		>>

Original		Replacement	
SCAN	<<		<<
SKIP	>>I		>>I
SKIP	I<<		I<<
DVD MENU	DVD Menu	E-MANUAL D.MENU	D. Menu
TITLE	Title	DISC NAV LIST	List
DISPLAY	Display	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
ENTER	Enter	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
AUDIO	O))/Audio	SOUND DUAL	Dual
SUBTITLE	[...]/Subtitle	AD SUBT	Subt
ANGLE	Camera/Angle	SETTINGS OPT	Options
SETUP	Setup	TOP MENU MENU	Menu
MARKER	Marker	APP MEDIA	Media

Original	Replacement	Original	Replacement
SEARCH Search	SEARCH TV/R TV/R		
PROGRAM Program	PROG SLEEP Sleep		
ZOOM Zoom	SHIFT + ZOOM Shift + Eject		
REPEAT Repeat	REPEAT TEXT Text		
A-B A-B	ECO 3D 3D		
RANDOM Random	HOME SMART Smart		
RESOLUTION Resolution	PICTURE FORMAT Format		
TV POWER Power Tv	SHIFT + Power Shift + Power		
AV AV Tv	TIMER AV AV		
PR/CH PR/CH+ Tv	+ CH Ch +		
PR/CH- Tv	CH − Ch -		
VOL Vol+ Tv	+ VOL Vol +		
Vol- Tv	VOL − Vol -		