Original		Replacement	
POWER	Power		Power
SOURCE	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
+	Vol+	+ VOL	Vol +
−	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute

Original		Replacement	
P	P+	+ CH	Ch +
P	P-	CH −	Ch -
CH LIST	CH List	DISC NAV LIST	List
SMART HUB	Smart Hub	HOME SMART	Smart
MENU	Menu	TOP MENU MENU	Menu
SEARCH	Search	SEARCH TV/R	TV/R
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
	Enter	OK	Ok
A	Red	A	Red
B	Green	B	Green

Original		Replacement	
C	Yellow	C	Yellow
D	Blue	D	Blue
SOCIAL TV	Social TV	APP MEDIA	Media
HDMI	HDMI	AD SUBT	Subt
3D	3D	ECO 3D	3D
E-MANUAL	E-Manual	E-MANUAL D.MENU	D. Menu
P.SIZE	P.Size	PICTURE FORMAT	Format
SRS	SRS	SOUND DUAL	Dual
<<	<<	<<	<<
I<<	I<<	I<<	I<<
Pause	Pause	Pause	Pause
>>	>>	>>	>>
>>I	>>I	>>I	>>I
Rec	Rec	REC MODE	Rec
Play	Play	PLAY MODE	Play
Stop	Stop	Stop	Stop

Original	Replacement