Original		Replacement	
	Power		Power
	Power AV	SHIFT +	Shift + Power
	Auto Cal	HOME SMART	Smart
	Sleep	PROG SLEEP	Sleep
	MD-TAPE	APP MEDIA	Media
	AMP MENU	TOP MENU MENU	Menu
	2CH	A	Red
	A.F.D.	B	Green
	Movie	C	Yellow
	Music	D	Blue
	1	1	1
	2	2	2
	3	3	3
	4	4	4
	5	5	5
	6	6	6
	7	7	7

Original		Replacement	
	8	8	8
	9	9	9
	0/10	0	0
	>10/* -/-- CLEAR	-/-- GUIDE	Guide
	DUAL MONO	SOUND DUAL	Dual
	FM MODE	SEARCH TV/R	TV/R
	DISPLAY	DISPLAY INFO	Info
	Up AMP Menu		Up
	Down AMP		Down
	Right AMP Menu		Right
	Left AMP Menu		Left
	OK MD/Tape	SHIFT + OK	Shift + Ok
	OK AMP Menu	OK	Ok
	TV VOL MASTER VOL +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	MUTING	MUTE	Mute
	TV CH − PRESET −	<<	<<

Original		Replacement	
TV CH + PRESET +	>>I / Preset +	>>I	>>I
TUNING –	<<I Tuning-	<<	<<
	Play	PLAY MODE ▶	Play
TUNING +	>>I Tuning+	>>	>>
	Pause	II	Pause
	Stop	■	Stop

Original	Replacement

Original		Replacement	
	Power		Power
	Power AV	SHIFT +	Shift + Power
	Auto Cal	HOME SMART	Smart
	Sleep	PROG SLEEP	Sleep
	2CH	A	Red
	A. F. D.	B	Green
	Movie	C	Yellow
	Music	D	Blue
	1	1	1
	2	2	2
	3	3	3
	4	4	4
	5	5	5
	6	6	6
	7	7	7
	8	8	8
	9	9	9

Original		Replacement	
	0/10	0	0
	>10/* -/-- CLEAR	-/-- GUIDE	Guide
	MEMORY ENTER	FAV PRE-CH	Pre Ch
	Menu	TOP MENU MENU	Menu
	DVD Menu	E-MANUAL D.MENU	D. Menu
	Return/Exit	CLEAR EXIT	Exit
	Tools	SETTINGS OPT	Options
	Display	DISPLAY INFO	Info
	D.Tuning/D.Skip	PICTURE FORMAT	Format
	FM Mode	SEARCH TV/R	TV/R
	Dual Mono	SOUND DUAL	Dual
	Muting	MUTE	Mute
	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -
	OK	OK	Ok
	Up		Up
	Down		Down

Original	Replacement
Right	Right
Left	Left
Play	Play
Pause	Pause
Stop	Stop
<<Tuning-	<<
>>Tuning+	>>
>>I / Preset +	>>I
I<< / Preset -	I<<
← / Replay	Ch -
· → / Advance	Ch +
DVD	Media
D. Tuning/ D. Skip Tuner	3D
Tuner	Shift + Media
Enter / Memory	Shift + Pre Ch
1 Tuner	Shift + 1
2 Tuner	Shift + 2

Original	Replacement
3 Tuner	Shift + 3
4 Tuner	Shift + 4
5 Tuner	Shift + 5
6 Tuner	Shift + 6
7 Tuner	Shift + 7
8 Tuner	Shift + 8
9 Tuner	Shift + 9
0/10 Tuner	Shift + 0
Display Tuner	Shift + Info
OK Tuner	Shift + Ok
Up Tuner	Shift + Up
Down Tuner	Shift + Down
Right Tuner	Shift + Right
Left Tuner	Shift + Left
<<Tuning- Tuner	Shift + <<
>>Tuning+	Shift + >>
I<<Preset - / Tv CH- Tuner	Shift + I<<

Original	Replacement	Original	Replacement
TV CH + PRESET + >>I / Preset +/ Tv CH+ Tuner	SHIFT + >>I Shift + >>I		

Original		Replacement	
	Power		Power
	Play	PLAY MODE	Play
	Stop		Stop
AUTO CAL	Auto Cal	HOME SMART	Smart
TV/VIDEO SLEEP	Sleep	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0/10	0/10	0	0
>10/* -/-- CLEAR	-/--/>10	-/-- GUIDE	Guide
	OK	OK	Ok

Original		Replacement	
MEMORY ENTER	Enter/Memory	FAV PRE-CH	Pre Ch
MENU	Menu	TOP MENU MENU	Menu
DISPLAY	Display	DISPLAY INFO	Info
MUTING	Muting	MUTE	Mute
TV VOL MASTER VOL +	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
DUAL MONO	Dual Mono	SOUND DUAL	Dual
FM MODE	FM Mode	PICTURE FORMAT	Format
2CH	2CH	A	Red
A.F.D.	A. F. D.	B	Green
MOVIE	Movie	C	Yellow
MUSIC	Music	D	Blue
	Pause		Pause

Original		Replacement		Original	Replacement
TUNING +	>>/ Tuning+	>>			
TUNING –	<</ Tuning-	<<			
TV CH + PRESET +	>>I / Preset +	>>I			
TV CH – PRESET –	I <</ Preset -	I <<			
REPLAY	← / Replay	CH –	Ch -		
ADVANCE	· →/ Advance	+ CH	Ch +		
VIDEO 3	Video 3	SHIFT + APP MEDIA	Shift + Media		
VIDEO 1	Video 1	APP MEDIA	Media		
AV I/⏻ SYSTEM	Power AV	TIMER AV	AV		
TV I/⏻ STANDBY	Tv Power	SHIFT + ⏻	Shift + Power		
TV/VIDEO SLEEP	Tv/ Video	SEARCH TV/R	TV/ R		
TV VOL MASTER VOL +	Tv Vol +	SHIFT + + VOL	Shift + Vol +		
–	Tv Vol -	SHIFT + VOL –	Shift + Vol -		
TV CH – PRESET –	Tv CH-	SHIFT + CH –	Shift + Ch -		
TV CH + PRESET +	Tv CH+	SHIFT + + CH	Shift + Ch +		

Original		Replacement	
	Power		Power
	Power AV	SHIFT +	Shift + Power
	Auto Cal	HOME SMART	Smart
	Sleep	PROG SLEEP	Sleep
	A.F.D.	B	Green
	Movie	C	Yellow
	Music	D	Blue
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0/10	0/10	0	0

Original		Replacement	
>10/* -/-- CLEAR	-/--/>10	-/-- GUIDE	Guide
MEMORY ENTER	Enter/Memory	FAV PRE-CH	Pre Ch
FM MODE	FM Mode	SEARCH TV/R	TV/R
DUAL MONO	Dual Mono	SOUND DUAL	Dual
DISPLAY	Display	DISPLAY INFO	Info
MUTING	Muting	MUTE	Mute
TV VOL MASTER VOL +	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
MENU	Menu	TOP MENU MENU	Menu
	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop

Original		Replacement	
TUNING –	<</ Tuning-	<<	
TUNING +	>>/ Tuning+	>>	
TV CH + PRESET +	>>I / Preset +	>>I	
TV CH – PRESET –	I <</ Preset -	I <<	
REPLAY	← / Replay	CH –	Ch -
ADVANCE	· →/ Advance	+ CH	Ch +
VIDEO 2	Video 2	APP MEDIA	Media
SA-CD/CD	SA- CD/ CD	SHIFT + APP MEDIA	Shift + Media
AV I/⏻ SYSTEM	Power AV	TIMER AV	AV
2CH	2CH	A	Red
D.TUNING D.SKIP	D. Tuning/ D. Skip SA- CD/ CD	PICTURE FORMAT	Format
MEMORY ENTER	Enter/ Memory SA- CD/ CD	SHIFT + FAV PRE-CH	Shift + Pre Ch
1	1 SA- CD/ CD	SHIFT + 1	Shift + 1
2	2 SA- CD/ CD	SHIFT + 2	Shift + 2
3	3 SA- CD/ CD	SHIFT + 3	Shift + 3
4	4 SA- CD/ CD	SHIFT + 4	Shift + 4
5	5 SA- CD/ CD	SHIFT + 5	Shift + 5

Original		Replacement	
6	6 SA- CD/ CD	SHIFT + 6	Shift + 6
7	7 SA- CD/ CD	SHIFT + 7	Shift + 7
8	8 SA- CD/ CD	SHIFT + 8	Shift + 8
9	9 SA- CD/ CD	SHIFT + 9	Shift + 9
0/10	0/ 10 SA- CD/ CD	SHIFT + 0	Shift + 0
>10/• -/-- CLEAR	-/--/>10 SA- CD/ CD	SHIFT + -/-- GUIDE	Shift + Guide
DISPLAY	Display SA- CD/ CD	SHIFT + DISPLAY INFO	Shift + Info
■	Stop SA- CD/ CD	SHIFT + ■	Shift + Stop
II	Pause	SHIFT + II	Shift + Pause
▷	Play SA- CD/ CD	SHIFT + PLAY MODE ▶	Shift + Play
TUNING –	<</ Tuning-	SHIFT + <<	Shift + <<
TUNING +	>>/ Tuning+	SHIFT + >>	Shift + >>
TV CH – PRESET –	I <</ Preset - SA- CD/ CD	SHIFT + I <<	Shift + I <<
TV CH + PRESET +	>>I / Preset + SA- CD/ CD	SHIFT + >>I	Shift + >>I