Mandis shop

Lauson CL144

Original		Replacement	
FIND	Find	HOME SMART	Smart
INFO	Info	DISPLAY INFO	Info
REP/ INTRO/RAN	Rep/Intro/Ran	OK	Ok
PROGRAM	Program	PROG SLEEP	Sleep
REC	Rec	REC MODE	Rec
▶II	Play	PLAY MODE ▶	Play
▶II	Pause	II	Pause
■	Stop	■	Stop
SKIP/SEA	I<<	<<	I<<
/SEARCH	Skip/Search	>>I	>>I
+10	+10	+ CH	Ch +
-10	-10	CH −	Ch -
SOURCE	Source	TIMER AV	AV
TS	TS	SOUND DUAL	Dual

Original	Replacement

https://alle-fernbedienungen.de/en/Lauson/1058039-85022-replacement-remote-control-for-Lauson-MP3-Digital-CL144.html