Mandis shop

LG AKB73975763

Original		Replacement	
Power	Power	Power	Power
INPUT	Input	RDS AV INPUT	AV / Input / RDS
ON	Monitor On	SHIFT + ▲	Shift + Up
MONITOR OFF	Monitor Off	SHIFT + ▼	Shift + Down
ENERGY SAVING	Energy Saving	LIST SMART	Smart / List
3D	3D	FORMAT PICTURE	Picture / Format
1	1	TV 1	1
2 ABC	2	DVD 2	2
3 DEF	3	CD-STB 3	3
4 GHI	4	VIDEO 4	4
5 JKL	5	TAPE 5	5
6 MNO	6	TUNER 6	6
7 PQRS	7	AUX-HDD 7	7
8 TUV	8	USB 8	8
9 WXYZ	9	BLUETOOTH 9	9
1/a/A	1/a/A	SHIFT + TV 1	Shift + 1
0	0	HDMI-SAT 0	0

Original		Replacement	
CLEAR	Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
◿	Vol +	+ VOL	Vol +
ARC	ARC	MEDIA DISPLAY	Display / Media
BRIGHTNESS (PAGE)	Brightness (Page)	+ CH PAGE	CH+ / Page+
◿	Vol -	VOL −	Vol -
AUTO	Auto	GOTO TEXT	Text / Goto
BRIGHTNESS (PAGE) Down	Brightness (Page) Down	CH PAGE −	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PSM	PSM	SHIFT + MEDIA DISPLAY	Shift + Display / Media
HOME	Home	HOME MENU	Menu / Home
W.BAL	W Bal	SIZE ZOOM	Zoom / Size
SETTINGS	Settings	OPT-TOOLS SETUP	Setup / OPT /
▲	Up	▲	Up
S.MENU	S. Menu	TOP MENU D.MENU	D. Menu / Top
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right

Original		Replacement		Original	Replacement
BACK	Back	RETURN BACK	Back / Return		
▼	Down	▼	Down		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
SIMPLINK	Simplink	SHIFT + LIST SMART	Shift + Smart / List		
TILE	Tile	TITLE SOUND	Sound / Title		
■	Stop	HOLD ■	Stop / Hold		
◀◀	<<	TUNE- ◀◀	<< / Tune-		
▶	Play	SLOW ▶	Play / Slow		
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze		
▶▶	>>	TUNE+ ▶▶	>> / Tune+		
ON PICTURE	Red/On Picture ID	NETFLIX SEARCH	Red / Netflix / Search		
OFF PICTURE ID	Green/Off Picture ID	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		