Mandis shop

Panasonic N2QAYB001029

Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CANCEL	Cancel	DISC NAV LIST	List
AUDIO	Audio	SOUND DUAL	Dual
OPEN/CLOSE	Open/Close	ZOOM	Eject
STATUS	Status	AD SUBT	Subt
PIP	PIP	ECO 3D	3D
INTERNET	Internet	SHIFT + APP MEDIA	Shift + Media

Original		Replacement	
SEARCH	<< Search		<<
PLAY	Play	PLAY MODE	Play
SEARCH	>> Search		>>
SKIP	I<<		I<<
SLOW PAUSE	Pause		Pause
SKIP	>>I		>>I
STOP	Stop		Stop
POP-UP MENU	Pop-Up/Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
TOP MENU	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
NETFLIX	Netflix	APP MEDIA	Media
HOME	Home	HOME SMART	Smart
OPTION	Option	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
	Up		Up
	Down		Down
	Right/I>		Right

Original		Replacement	
	Left		Left
OK	OK	OK	Ok
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	Power Tv	SHIFT +	Shift + Power
+ VOL	Vol+ Tv	+ VOL	Vol +
INPUT AV	AV Input Tv	TIMER AV	AV
VOL −	Vol- Tv	VOL −	Vol -

Original	Replacement