| Original | | Replacement | |
|---|---|---|---|
| DVD/VHS | DVD/VHS Power | | Power |
| TV | TV Power | SHIFT + | Shift + Power |
| CH | TV CH + | SHIFT + CH PAGE | Shift + CH+ / |
| VOLUME | TV Volume + | VOL | Vol + |
| DRIVE SELECT | Drive Select | LIST SMART | Smart / List |
| AV | TV AV | SHIFT + RDS AV INPUT | Shift + AV / Input / RDS |
| CH | TV CH - | SHIFT + CH PAGE | Shift + CH- / |
| | TV Volume - | VOL | Vol - |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| CH | CH + / Tracking/V-Lock | CH PAGE | CH+ / Page+ |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| CH | CH - / Tracking/V-Lock | CH PAGE | CH- / Page- |
| 7 | 7 | AUX-HDD 7 | 7 |

| Original | | Replacement | |
|---|---|---|---|
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| ShowView | ShowView | TITLE SOUND | Sound / Title |
| * RESET | * / Reset | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 | HDMI-SAT 0 | 0 |
| INPUT SELECT | Input Select | RDS AV INPUT | AV / Input / RDS |
| DELETE | Delete | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| SKIP/I | I<< | PRESET- | I<< / Preset- |
| SKIP/INDEX | >>I | PRESET+ | >>I / Preset+ |
| REW | << | TUNE- | << / Tune- |
| FF | >> | TUNE+ | >> / Tune+ |
| STOP | Stop | HOLD | Stop / Hold |
| PAUSE | Pause | STEP-FREEZE | Pause / Step / Freeze |
| PLAY | Play | SLOW | Play / Slow |
| TIME SLIP/JET REW | Time Slip / << J Rew | SHIFT + TUNE- | Shift + << / |
| MANUAL SKIP | Manual Skip | TIMER SLEEP | Sleep / Timer |
| PROG/CHECK | Prog Check | OPT-TOOLS SETUP | Setup / OPT / Tools |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Direct Navigator | TOP MENU D.MENU — D. Menu / Top | | |
| Left / ◁II | Left | | |
| Enter | OK — OK | | |
| Up | Up | | |
| Right / II▷ | Right | | |
| Functions | HOME MENU — Menu / Home | | |
| SUB MENU S — Sub Menu | ANGLE INFO — Info / Angle | | |
| Down | Down | | |
| RETURN — Return | RETURN BACK — Back / Return | | |
| AUDIO A — Audio | LANG I/II AUDIO — Audio / Lang I/II | | |
| DISPLAY B — Display | MEDIA DISPLAY — Display / Media | | |
| CREATE CHAPTER C — Create Chapter | PROGRAM TV/RADIO — TV/Radio / | | |
| STATUS — Status | FORMAT PICTURE — Picture / Format | | |
| REC — Rec | REC MODE — Rec / Rec Mode | | |
| REC MODE — Rec Mode | SHIFT + REC MODE — Shift + Rec / Rec Mode | | |
| EXT LINK — Ext Link | GOTO TEXT — Text / Goto | | |
| DIRECT TV REC — Direct TV Rec | SIZE ZOOM — Zoom / Size | | |