Original	Replacement	Original	Replacement
Power	Power	OK	Ok
1	1	Right	Right
2	2	Down	Down
3	3	I <<	I <<
4	4	I <<	<<
5	5	>>I	>>I
6	6	>>I	>>
7	7	Stop	Stop
8	8	Play	Play
9	9	Pause	Pause
0	0	DISC	Green
Disc Menu	D. Menu	TV	Red
Display Menu	Info	TUNER	Yellow
Vol +	Vol +	AUX/DI	Blue
Vol -	Vol -	Subtitle	Subt
Up	Up	Audio	Dual
Left	Left	Zoom	Eject

Original	Replacement	Original	Replacement
Set up	Menu		
Repeat	Text		
Pr og	Shi f t + Sl eep		
Sl eep	Sl eep		
Mut e	Mut e		
Sound	Shi f t + Dual		
SURR	For mat		
TV Vol +	Ch +		
TV Vol -	Ch -		

Original	Replacement	Original	Replacement
Power	Power	Right	Right
1	1	Down	Down
2	2	I<<	I<<
3	3	I<<	<<
4	4	>>I	>>
5	5	>>I	>>I
6	6	Stop	Stop
7	7	Play	Play
8	8	DISC	Green
9	9	TV	Red
0	0	TUNER	Yellow
Display Menu	Info	AUX/DI	Blue
Vol +	Vol +	Setup	Menu
Vol -	Vol -	Mute	Mute
Up	Up	Sound	Dual
Left	Left	SURR	Format
OK	Ok	TV Vol +	Ch +

Original	Replacement	Original	Replacement
TV Vol -	Ch -		

Original	Replacement	Original	Replacement
Power	Power	Right	Right
1	1	Down	Down
2	2	I <<	I <<
3	3	I <<	<<
4	4	>>I	>>I
5	5	>>I	>>
6	6	Stop	Stop
7	7	Play	Play
8	8	DISC	Green
9	9	TV	Red
0	0	TUNER	Yellow
Display Menu	Info	AUX/DI	Blue
Vol +	Vol +	Prog	Sleep
Vol -	Vol -	Mute	Mute
Up	Up	Sound	Dual
Left	Left	SURR	Format
OK	Ok	TV Vol +	Ch +

Original	Replacement	Original	Replacement
TV VOL – TV Vol -	CH – Ch -		

Original	Replacement	Original	Replacement
Power	Power	Ri ght	Ri ght
1	1	Down	Down
2	2	I <<	I <<
3	3	I <<	<<
4	4	>>I	>>I
5	5	>>I	>>
6	6	St op	St op
7	7	Pl ay	Pl ay
8	8	Pause	Pause
9	9	DI SC	Gr een
0	0	TV	Red
Di spl ay Menu	I nf o	TUNER	Yel l ow
Vol +	Vol +	AUX/ DI	Bl ue
Vol -	Vol -	Pr og	Sl eep
Up	Up	Set up	Menu
Lef t	Lef t	Mut e	Mut e
OK	Ok	SURR	For mat