Original	Replacement	Original	Replacement
Power	Power	Left	Left
TV / Video	TV/R	OK	Ok
DVD	Smart	Right	Right
VCR	Media	Down	Down
Open / Close	Eject	Stop	Stop
1	1	Play	Play
2	2	Pause / Step	Pause
3	3	<< REW	<<
4	4	>> FWD	>>
5	5	Record	Rec
6	6	Clear	Exit
7	7		
8	8		
9	9		
0	0		
Display	Info		
Up	Up		

Original	Replacement	Original	Replacement
Power	Power	System Menu	Menu
Open / Close	Eject	Up	Up
DVD	Smart	Left	Left
VCR	Media	OK	Ok
1	1	Right	Right
2	2	Down	Down
3	3	I <	I <<
4	4	>I	>>I
5	5	Stop	Stop
6	6	Play	Play
7	7	Pause / Step	Pause
8	8	<< REW	<<
9	9	>> FWD	>>
0	0	Thumbnail	3D
Return	Back	Chapter	Format
Display	Info	Timer	AV
List / Disc Men	D. Menu	Record	Rec

Original	Replacement	Original	Replacement
Rec. Mode	Blue		
Repeat	Text		
Title	Options		
Audio	Dual		
Zoom	Shift + Eject		
Search	TV/R		
Marker	Pre Ch		
D. Dubbing	Guide		
Clear	Exit		
Showview / VideoPlus+	Subt		