Mandis shop

Medion MSN40009114

Original		Replacement	
TV	TV	SHIFT + TV 1	Shift + 1
AV.SV	AV.SV	RDS AV INPUT	AV / Input / RDS
SCART1	SCART1	SHIFT + CD - STB 3	Shift + 3
PC	PC	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
SCART2	SCART2	SHIFT + DVD 2	Shift + 2
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
P+	Up / P+		Up
P+	Up / P+	CH PAGE +	CH+ / Page+
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOL-	Left / Vol-		Left
VOL-	Left / Vol-	VOL −	Vol-
MENU	Menu / Enter	OK	OK
MENU	Menu / Enter	HOME MENU	Menu / Home
VOL+	Right / Vol+		Right
VOL+	Right / Vol+	VOL +	Vol+
P−	Down / P-		Down
P−	Down / P-	CH PAGE −	CH- / Page-

Original		Replacement	
	Text	GOTO TEXT	Text / Goto
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	Green	APP REPEAT	Green / APP / Repeat
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+100	+100	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
RTN	RTN	RETURN BACK	Back / Return

Original		Replacement	
RTN	RTN	PC FAV MARKER	Fav / Marker / PC
SOUND	Sound	TITLE SOUND	Sound / Title
PIP SOURCE ▲	PIP Source Up	SHIFT + ▲	Shift + Up
DISPLAY	Display	MEDIA DISPLAY	Display / Media
POSITION	PIP Position	SHIFT + ◀	Shift + Left
ON/OFF PIP	PIP On/Off	SHIFT + OK	Shift + OK
SIZE	PIP Size	SHIFT + ▶	Shift + Right
APC	APC	TOP MENU D.MENU	D.Menu / Top
PIP SOURCE ▼	PIP Source	SHIFT + ▼	Shift + Down
ARC	ARC	OPT-TOOLS SETUP	Setup / OPT /
[▯]	[▯]	HOLD ■	Stop / Hold
[≡i]	[≡i]	SLOW ▶	Play / Slow
[↕]	[↕]	TUNE+ ▶▶	>> / Tune+
[≡?]	[≡?]	STEP-FREEZE ❚❚	Pause / Step / Freeze
[◷]	[◷]	PRESET- ⏮	I<< / Preset-
[≡X]	[≡X]	TUNE- ◀◀	<< / Tune-
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer

Original		Replacement	
RESET	Reset	LIST SMART	Smart / List
POWER	Power	⏻	Power