Original		Replacement		Original		Replacement	
POWER	Power		Power	>>	>>		>>
AMP POWER	Power AMP		+ Shift + Power	+ PRESET	Preset +		Ch +
CD	CD		Red	PRESET −	Preset -		Ch -
RECORDER	Recorder		Green	FAVORITE PURE DIRECT	Pure Direct/Favorite		Pre Ch
NETWORK	Network		Yellow	VOLUME ▲	Vol +		Vol +
PHONO	Phono		Blue	VOLUME ▼	Vol -		Vol -
AUX	AUX		Smart	MUTE	Mute		Mute
TUNER	Tuner	SC NA	Media	INFO	Info		Info
1	Internet Radio Preset 1		+ Shift + 1	MODE	Mode		Format
2	Internet Radio Preset 2		+ Shift + 2	SOURCE	Source		AV
3	Internet Radio Preset 3		+ Shift + 3	MENU	Menu	P	Menu
►/II	Play		Play	▲	Up	AY MOD	Up
►/II	Pause		Pause	▼	Down		Down
I<<	I <<		I <<	►	Right		Right
>>I	>>I		>>I	◄	Left		Left
■	Stop		Stop	ENTER	Enter		Ok
<<	<<		<<	1 ./	1		1

Original		Replacement		Original	Replacement
2 ABC	2		2		
3 DEF	3		3		
4 GHI	4		4		
5 JKL	5	PROG	5		
6 MNO	6		6		
7 PQRS	7		7		
8 TUV	8	SLEEP	8		
9 WXYZ	9		9		
0	0		0		
+10	+10		Guide		
CLEAR	Clear		Exit		
RANDOM	Random		Options		
REPEAT	Repeat	TV	Text		
PROGRAM SEARCH	Search/Program		Sleep		
DIMMER	Dimmer		Dual		

Original		Replacement	
POWER	Power		Power
AMP POWER	Power AMP		+ Shift + Power
CD	CD		Red
RECORDER	Recorder		Green
NETWORK	Network		Yellow
PHONO	Phono		Blue
AUX	AUX		Smart
TUNER	Tuner	SC NA	Media
►/II	Play		Play
►/II	Pause		Pause
I<<	I<<		I<<
>>I	>>I		>>I
■	Stop		Stop
<<	<<		<<
>>	>>		>>
+ PRESET	Preset +		Ch +
— PRESET	Preset -		Ch -

Original		Replacement	
FAVORITE PURE DIRECT	Pure Direct/Favorite		Pre Ch
VOLUME ▲	Vol +		Vol +
VOLUME ▼	Vol -		Vol -
MUTE	Mute		Mute
INFO	Info		Info
MODE	Mode		Format
SOURCE	Source		AV
MENU	Menu	P	Menu
▲	Up	AY MOD	Up
▼	Down		Down
►	Right		Right
◄	Left		Left
ENTER	Enter		Ok
1 ./	1		1
2 ABC	2	IST	2
3 DEF	3		3
4 GHI	4		4

Original		Replacement		Original	Replacement
5 JKL	5	PROG	5		
6 MNO	6		6		
7 PQRS	7		7		
8 TUV	8	LEEP	8		
9 WXYZ	9		9		
0	0		0		
+10	+10		Gui de		
CLEAR	Cl ear		Exi t		
RANDOM	Random		Opt i ons		
REPEAT	Repeat		Text		
PROGRAM SEARCH	Sear ch/ Pr ogr am		Sl eep		
DIMMER	Di mmer		Dual		