Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Recall/Last View		Pre Ch
	Radio/Tv		TV/R
	CH/Page+		Ch +
	CH/Page-		Ch -
	Internet		Smart
	Skype		Media

Original		Replacement	
	I<< Skip		I<<
	Skip >>I		>>I
	<< Slow/Search		<<
	Slow/Search >>		>>
	Stop		Stop
	Pause		Pause
	Play		Play
	i/Status		Info
	X/Exit		Exit
	Option		Options
	Return		Back
	Direct Navigator		List
	Guide		Guide
	Function Menu		Menu
	Up		Up
	Down		Down
	Right		Right

Original		Replacement	
	Left		Left
OK	OK	OK	Ok
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
REC	Rec	REC MODE	Rec
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec
TEXT	Text	REPEAT TEXT	Text
STTL	STTL	AD SUBT	Subt
PROG/CHECK	Prog/Check	PROG SLEEP	Sleep
CHAPTER	Chapter	TIMER AV	AV
TIME SLIP	Time Slip	ZOOM	Eject
AUDIO	Audio	SOUND DUAL	Dual
DRIVE SELECT	Drive Select	E-MANUAL D.MENU	D. Menu
DEL	Del	SHIFT + CLEAR EXIT	Shift + Exit
MANUAL -10s	Manual Skip -10s	PICTURE FORMAT	Format

Original		Replacement	
MANUAL SKIP +60s	Manual Skip +60s	ECO 3D	3D
TV	Power Tv	SHIFT +	Shift + Power
INPUT AV	Av Input Tv	SHIFT + TIMER AV	Shift + AV
+ VOL	Vol+ Tv	+ VOL	Vol +
VOL	Vol- Tv	VOL −	Vol -
CH	CH+ Tv	SHIFT + + CH	Shift + Ch +
CH	CH- Tv	SHIFT + CH −	Shift + Ch -