| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| | Power | | Power | | Enter | | Ok |
| | Display | | Info | | Right | | Right |
| | DVD / BD | | Shift + 1 | | Down | | Down |
| | VCR / DVR | | Shift + 2 | | Setup | | Options |
| | CBL/SAT | | Shift + 3 | | Return | | Back |
| | CD | | Shift + 4 | | Audio | | Dual |
| | AUX | | Shift + 5 | | I<< | | I<< |
| | TV / TAPE | | Shift + 6 | | >>I | | >>I |
| | TUNER | | Shift + 7 | | << | | << |
| | PORT | | Shift + 8 | | Play | | Play |
| | Muting | | Mute | | >> | | >> |
| | CH/Disc/Album | | Ch + | | Pause | | Pause |
| | CH/Disc/Album | | Ch - | | Stop | | Stop |
| | Vol + | | Vol + | | Movie | | Red |
| | Vol - | | Vol - | | Music/Repeat | | Green |
| | Up | | Up | | Game/Random | | Yellow |
| | Left | | Left | | Stereo/Play Mode | | Blue |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| 1 | 1 | 1 | 1 | | | | |
| 2 | 2 | 2 | 2 | | | | |
| 3 | 3 | 3 | 3 | | | | |
| 4 | 4 | 4 | 4 | | | | |
| 5 | 5 | 5 | 5 | | | | |
| 6 | 6 | 6 | 6 | | | | |
| 7 | 7 | 7 | 7 | | | | |
| 8 | 8 | 8 | 8 | | | | |
| 9 | 9 | 9 | 9 | | | | |
| 11 0 | 0/ 11 | 0 | 0 | | | | |
| 10 +10 D.TUN DIMMER | +10/ - - / - - - 10/ Di mer / D. Tun | -/-- GUIDE | Gui de | | | | |
| 12 CLR SLEEP | CLR/ Sl eep/ 12 | FAV PRE-CH | Pre Ch | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| Original | | Replacement | |
|---|---|---|---|
| Power BD/DVD | | Power | |
| Menu/Prev CH | | Menu | |
| Top Menu/Guide BD/DVD | | Options | |
| Setup BD/DVD | | Smart | |
| Return BD/DVD | | Back | |
| Audio BD/DVD | | Media | |
| Enter BD/DVD | | Ok | |
| Up BD/DVD | | Up | |
| Down BD/DVD | | Down | |
| Right BD/DVD | | Right | |
| Left BD/DVD | | Left | |
| I<< BD/DVD | | I<< | |
| >>I BD/DVD | | >>I | |
| << BD/DVD | | << | |
| >> BD/DVD | | >> | |
| Play BD/DVD | | Play | |
| Pause/Play rev. BD/DVD | | Pause | |

| Original | | Replacement | |
|---|---|---|---|
| Stop BD/DVD | | Stop | |
| Movie Tv/Search BD/DVD | | Red | |
| Music/Repeat | | Green | |
| Game/Random | | Yellow | |
| Stereo/Play Mode BD/DVD | | Blue | |
| 1 BD/DVD | | 1 | |
| 2 BD/DVD | | 2 | |
| 3 BD/DVD | | 3 | |
| 4 BD/DVD | | 4 | |
| 5 BD/DVD | | 5 | |
| 6 BD/DVD | | 6 | |
| 7 BD/DVD | | 7 | |
| 8 BD/DVD | | 8 | |
| 9 BD/DVD | | 9 | |
| 0/11 BD/DVD | | 0 | |
| +10/--/--10/D.Tun Dimmer BD/DVD | | Guide | |
| CLR/Sleep/12 | | Pre Ch | |

BD/DVD

| Original | Replacement |
|---|---|
| CBL/SAT | REPEAT TEXT Text |
| Muting Receiver | MUTE Mute |
| Vol + Receiver | VOL + Vol + |
| Vol - Receiver | VOL − Vol - |
| Power CBL/SAT | SHIFT + Power Shift + Power |
| CH Disc/Album+ CBL/SAT | CH + Ch + |
| CH Disc/Album- CBL/SAT | CH − Ch - |
| Menu/Prev CH CBL/SAT | SHIFT + TOP MENU MENU Shift + Menu |
| Top Menu/Guide CBL/SAT | SHIFT + SETTINGS OPT Shift + Options |
| Return CBL/SAT | SHIFT + RETURN BACK Shift + Back |
| Setup CBL/SAT | SHIFT + HOME SMART Shift + Smart |
| Up CBL/SAT | SHIFT + Shift + Up |
| Enter CBL/SAT | SHIFT + OK Shift + Ok |
| Down CBL/SAT | SHIFT + Shift + Down |
| Right CBL/SAT | SHIFT + Shift + Right |
| Left CBL/SAT | SHIFT + Shift + Left |
| Pause/Play rev. CBL/SAT | SHIFT + Shift + Pause |

| Original | Replacement |
|---|---|
| Stop CBL/SAT | SHIFT + Shift + Stop |
| << CBL/SAT | SHIFT + CH − Shift + Ch - |
| >> CBL/SAT | SHIFT + CH + Shift + Ch + |
| Play CBL/SAT | ECO 3D 3D |
| Movie Tv/Search CBL/SAT | SOUND DUAL Dual |
| Music/Repeat CBL/SAT | AD SUBT Subt |
| Game/Random | TIMER AV AV |
| Stereo/Play Mode CBL/SAT | PICTURE FORMAT Format |
| 1 CBL/SAT | SHIFT + 1 Shift + 1 |
| 2 CBL/SAT | SHIFT + 2 Shift + 2 |
| 3 CBL/SAT | SHIFT + 3 Shift + 3 |
| 4 CBL/SAT | SHIFT + 4 Shift + 4 |
| 5 CBL/SAT | SHIFT + 5 Shift + 5 |
| 6 CBL/SAT | SHIFT + 6 Shift + 6 |
| 7 CBL/SAT | SHIFT + 7 Shift + 7 |
| 8 CBL/SAT | SHIFT + 8 Shift + 8 |
| 9 CBL/SAT | SHIFT + 9 Shift + 9 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| 11 0 | 0/ 11 CBL/ SAT | SHIFT + 0 | Shift + 0 | | |
| DVD/BD | DVD/ BD | SEARCH TV/R | TV/ R | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power CD | | Power |
| | CH/Disc+ CD | | Ch + |
| | CH/Disc- CD | | Ch - |
| | Return CD | | Back |
| | Setup CD | | Smart |
| | Audio CD | | Media |
| | Up CD | | Up |
| | Down CD | | Down |
| | Right CD | | Right |
| | Left CD | | Left |
| | Enter CD | | Ok |
| | I<< CD | | I<< |
| | >>I CD | | >>I |
| | << CD | | << |
| | >> CD | | >> |
| | Play CD | | Play |
| | Pause CD | | Pause |

| Original | | Replacement | |
|---|---|---|---|
| | Stop CD | | Stop |
| | Movie Tv/Search | | Red |
| | Music/Repeat | | Green |
| | Game/Random | | Yellow |
| | Stereo/Play Mode | | Blue |
| | 1 CD | | 1 |
| | 2 CD | | 2 |
| | 3 CD | | 3 |
| | 4 CD | | 4 |
| | 5 CD | | 5 |
| | 6 CD | | 6 |
| | 7 CD | | 7 |
| | 8 CD | | 8 |
| | 9 CD | | 9 |
| | 0/11 CD | | 0 |
| | +10/--/--10/D.Tu Dimmer CD | | Guide |
| | CLR/Sleep/12 | | Pre Ch |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| MUTING | Muting Receiver | MUTE | Mute | | | | |
| VOL | Vol + Receiver | + VOL | Vol + | | | | |
| VOL | Vol - Receiver | VOL − | Vol - | | | | |
| CD | CD | SEARCH TV/R | TV/R | | | | |

| Original | | Replacement | |
|---|---|---|---|
| ON/STANDBY | Power Receiver Zone 2 | | Power |
| MUTING | Muting Receiver | MUTE | Mute |
| VOL | Vol + Zone 2 | VOL + | Vol + |
| VOL | Vol - Zone 2 | VOL − | Vol - |
| CH DISC | CH Disc/Album+ Zone 2 | CH + | Ch + |
| ALBUM | CH Disc/Album- Zone 2 | CH − | Ch - |
| | Up Zone 2 | | Up |
| ENTER | Enter Zone 2 | OK | Ok |
| | Down Zone 2 | | Down |
| PLAYLIST /CATEGORY | Right Zone 2 | | Right |
| PLAYLIST /CATEGORY | Left Zone 2 | | Left |
| RETURN | Return Zone 2 | RETURN BACK | Back |
| SETUP | Setup Zone 2 | HOME SMART | Smart |
| AUDIO | Audio Zone 2 | APP MEDIA | Media |
| | I<< Zone 2 | | I<< |
| | >>I Zone 2 | | >>I |
| | Play Zone 2 | PLAY MODE | Play |

| Original | | Replacement | |
|---|---|---|---|
| | >> Zone 2 | | >> |
| | << Zone 2 | | << |
| | Pause Zone 2 | | Pause |
| | Stop Zone 2 | | Stop |
| MOVIE/TV SEARCH | Movie Tv/Search Zone 2 | A | Red |
| LISTENI MUSIC REPEAT | Music/Repeat | B | Green |
| G MODE GAME RANDOM | Game/Random | C | Yellow |
| STEREO PLAY MODE | Stereo/Play Mode Zone 2 | D | Blue |
| 1 | 1 Zone 2 | 1 | 1 |
| 2 | 2 Zone 2 | 2 | 2 |
| 3 | 3 Zone 2 | 3 | 3 |
| 4 | 4 Zone 2 | 4 | 4 |
| 5 | 5 Zone 2 | 5 | 5 |
| 6 | 6 Zone 2 | 6 | 6 |
| 7 | 7 Zone 2 | 7 | 7 |
| 8 | 8 Zone 2 | 8 | 8 |
| 9 | 9 Zone 2 | 9 | 9 |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| 11 0 | 0/11 Zone 2 | 0 | 0 | | | | |
| +10 D.TUN DIMMER | +10/- -/- -10/D.Tu Dimmer Zone 2 | -/-- GUIDE | Guide | | | | |
| 12 CLR SLEEP | CLR/Sleep/12 | FAV PRE-CH | Pre Ch | | | | |