Original		Replacement	
ON/OFF	On/Off	ON/OFF	Power
MUTE	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TV GUIDE	Tv Guide	GUIDE	Guide
	Recall	FAV PRE-CH	Pre Ch
VOL +	Vol+	VOL +	Vol +
VOL −	Vol-	VOL −	Vol -
PICTURE	Picture	PICTURE FORMAT	Format

Original		Replacement	
SOUND	Sound	SOUND DUAL	Dual
SOURCE	Source	TIMER AV	AV
CH +	CH+	CH +	Ch +
CH −	CH-	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch
BACK	Back	RETURN BACK	Back
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
OK	OK	OK	Ok
INFO	Info	DISPLAY INFO	Info
TEXT	Text	REPEAT TEXT	Text
SUBTITLE	Subtitle	AD SUBT	Subt
TV	TV	SEARCH TV/R	TV/R

Original		Replacement		Original	Replacement
YouTube		APP MEDIA	Media		
Netflix		HOME SMART	Smart		
Net+		SHIFT + APP MEDIA	Shift + Media		
Rec/DVD Menu		REC MODE	Rec		
I<<		I<<			
>>I		>>I			
Stop		Stop			
<<		<<			
>>		>>			
Play		PLAY MODE	Play		
Pause		Pause			
Rec List/DVD		DISC NAV LIST	List		
Red/Goto		A	Red		
Green/A-B		B	Green		
Yellow/Angle		C	Yellow		
Blue/Repeat		D	Blue		