Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
TV	TV	PROGRAM TV/ RADIO	TV/ Radio /
DVD	DVD	SHIFT + DVD 2	Shift + 2
RADIO	Radio	SHIFT + PROGRAM TV/ RADIO	Shift + TV/ Radio / Program
REC-MENU	Rec Menu	SHIFT + REC MODE	Shift + Rec / Rec Mode
	-[ ]-/ ←AB	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
	Audio	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD - STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX - HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9

Original		Replacement	
0 AV	0/ AV	HDMI - SAT 0	0
DVD-AV EPG	EPG/ DVD- AV	-/-- GUIDE EPG	Guide / EPG / -/--
CARD ASSIST	Assist/ Card	LIST SMART	Smart / List
PIP	PIP	FORMAT PICTURE	Picture / Format
DISC-M TEXT	Text/ Disc- M	GOTO TEXT	Text / Goto
MENU	Menu	HOME MENU	Menu / Home
END	End	CLEAR EXIT CANCEL	Exit / Cancel / Clear
INFO	Info	ANGLE INFO	Info / Angle
+V	Vol +	+ VOL	Vol +
	Up		Up
P+	P+	+ CH PAGE	CH+ / Page+
	Left		Left
OK	OK	OK	OK
	Right		Right
-V	Vol -	VOL –	Vol -
	Down		Down
P–	P-	CH PAGE –	CH- / Page-

Original	Replacement	Original	Replacement
Red/ C- Set	Red / Netflix / Search		
Green/ SV	Green / APP / Repeat		
Yellow/ Zoom	Yellow / YouTube / Repeat		
Blue/ Marker	Blue / Prime Video / Random		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Rec	Shift + Stop /		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		

Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
TV	TV	PROGRAM TV/RADIO	TV/Radio /
DVD	DVD	SHIFT + DVD 2	Shift + 2
RADIO	Radio	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
REC-MENU	Rec Menu	SHIFT + REC MODE	Shift + Rec / Rec Mode
AB	-[ ]-/←AB	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
	Audio	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD-STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX-HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9

Original		Replacement	
0 AV	0/AV	HDMI-SAT 0	0
DVD-AV EPG	EPG/DVD-AV	-/-- GUIDE EPG	Guide / EPG / -/--
CARD ASSIST	Assist/Card	LIST SMART	Smart / List
PIP	PIP	FORMAT PICTURE	Picture / Format
DISC-M TEXT	Text/Disc-M	GOTO TEXT	Text / Goto
MENU	Menu	HOME MENU	Menu / Home
END	End	CLEAR EXIT CANCEL	Exit / Cancel / Clear
INFO	Info	ANGLE INFO	Info / Angle
+V	Vol +	+ VOL	Vol +
	Up		Up
P+	P+	+ CH PAGE	CH+ / Page+
	Left		Left
OK	OK	OK	OK
	Right		Right
-V	Vol -	VOL −	Vol -
	Down		Down
P-	P-	CH PAGE −	CH- / Page-

Original	Replacement	Original	Replacement
Red/ C- Set	Red / Netflix / Search		
Green/ SV	Green / APP / Repeat		
Yellow/ Zoom	Yellow / YouTube / Repeat		
Blue/ Marker	Blue / Prime Video / Random		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec	SHIFT + HOLD Shift + Stop /		
Rec	REC MODE Rec / Rec Mode		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		

Original	Replacement
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
>>	>> / Tune+
Audio	Audio / Lang I/II
PIP	Picture / Format
Tv	TV/Radio /
Text/Disc-M	Text / Goto
Menu	Menu / Home
Up	Up
Info	Info / Angle
Left	Left
OK	OK

Original	Replacement
Right	Right
End	Exit / Cancel / Clear
Down	Down
Vol +	Vol +
Assist/Card	Smart / List
P+	CH+ / Page+
Vol -	Vol -
P-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9

Original	Replacement	Original	Replacement
EPG/ DVD- AV	Gui de / EPG / -/- -		
0/ AV	0		
Red/ C- Set	Red / Netflix / Search		
Green/ SV	Green / APP / Repeat		
Yel l ow/ Zoom	Yel l ow / YouTube / Repeat		
Bl ue/ Mar ker	Bl ue / Pri me Vi deo / Random		
Rec	Shi f t + Stop /		
Rec Menu	Shi f t + Rec / Rec Mode		
Radi o	Shi f t + TV/ Radi o / Program		
DVD	Shi f t + 2		
- [ ] - / ←AB	Shi f t + Yel l ow / YouTube /		

Original	Replacement	Original	Replacement
Power	Power	Right	Right
Mute	Mute / Dimmer	End	Exit / Cancel / Clear
Play	Play / Slow	Down	Down
Pause	Pause / Step / Freeze	Vol +	Vol +
Stop	Stop / Hold	Assist/Card	Smart / List
Rec	Rec / Rec Mode	P+	CH+ / Page+
<<	<< / Tune-	Vol -	Vol -
>>	>> / Tune+	P-	CH- / Page-
Audio	Audio / Lang I/II	1	1
PIP	Picture / Format	2	2
TV	TV/Radio /	3	3
Text/Disc-M	Text / Goto	4	4
Menu	Menu / Home	5	5
Up	Up	6	6
Info	Info / Angle	7	7
Left	Left	8	8
OK	OK	9	9

Original	Replacement	Original	Replacement
EPG/ DVD- AV	GUIDE EPG Gui de / EPG / -/- -		
0/ AV	HDMI - SAT 0 0		
Red/ C- Set	NETFLIX SEARCH Red / Netflix / Search		
Green/ SV	APP REPEAT Green / APP / Repeat		
Yellow/ Zoom	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue/ Marker	Prime Video RANDOM Blue / Prime Video / Random		
Rec	SHIFT + HOLD Shift + Stop /		
Rec Menu	SHIFT + REC MODE Shift + Rec / Rec Mode		
Radio	SHIFT + PROGRAM TV/ RADIO Shift + TV/ Radio / Program		
DVD	SHIFT + DVD 2 Shift + 2		
- [ ] - / ←AB	SHIFT + YouTube REPEAT A-B Shift + Yellow / YouTube /		