Original		Replacement	
STANDBY	Power		Power
MUTE	Mute	MUTE	Mute
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
	<<		<<
	>>		>>
	I <<		I <<
	>>I		>>I
RECORD	Record	REC MODE	Rec
OK	OK	OK	Ok
CH+	Up		Up
CH+	CH+	CH +	Ch +
CH-	CH-	CH -	Ch -
CH-	Down		Down
VOL +	Right		Right
VOL +	Vol +	VOL +	Vol +

Original		Replacement	
VOL -	Left		Left
VOL -	Vol -	VOL -	Vol -
INFO	Info	DISPLAY INFO	Info
RETURN/EXIT	Return/Exit	RETURN BACK	Back
SETUP	Setup	SETTINGS OPT	Options
DVD/DVB	DVD/DVB	HOME SMART	Smart
GOTO	Goto	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
PROG	Prog	PROG SLEEP	Sleep
TITLE/TTX	Title/TTX	REPEAT TEXT	Text
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
SLOW	Slow	ECO 3D	3D
EPG	EPG	-/-- GUIDE	Guide
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R
OPEN/CLOSE	Open/Close	ZOOM ⏏	Eject
FAVORITE	Favorite	FAV PRE-CH	Pre Ch
REPEAT	Red/Repeat	A	Red
REPEAT	Red/Repeat	SHIFT + REPEAT TEXT	Shift + Text
A-B	Green/A-B	B	Green
MENU	Yellow/Menu	C	Yellow
MENU	Yellow/Menu	TOP MENU MENU	Menu
ANGLE	Blue/Angle	D	Blue
P/N	PN	TIMER AV	AV

Original	Replacement