Original		Replacement	
ON/OFF	On/Off		Power
Freeview Play	Freeview Play	SETTINGS OPT	Options
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Mute	MUTE	Mute
TV GUIDE	Tv Guide	-/-- GUIDE	Guide
VOL +	Vol+	VOL +	Vol +
VOL −	Vol-	VOL −	Vol -
PICTURE	Picture	PICTURE FORMAT	Format

Original		Replacement	
SOUND	Sound	SOUND DUAL	Dual
SOURCE	Source	TIMER AV	AV
CH +	CH+	CH +	Ch +
CH −	CH-	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
BACK	Back	RETURN BACK	Back
FAV	FAV	FAV PRE-CH	Pre Ch
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
INFO	Info	DISPLAY INFO	Info
TEXT	Text	REPEAT TEXT	Text
SUBTITLE	Subtitle	AD SUBT	Subt
TV	TV	SEARCH TV/R	TV/R

Original		Replacement		Original	Replacement
NETFLIX	Netflix	APP MEDIA	Media		
You Tube	You Tube	HOME SMART	Smart		
APPs	APPs	SHIFT + APP MEDIA	Shift + Media		
DVD MENU	Rec/DVD Menu	REC MODE	Rec		
⏮	I<<	⏮	I<<		
⏭	>>I	⏭	>>I		
■	Stop	■	Stop		
⏪	<<	⏪	<<		
⏩	>>	⏩	>>		
⏯	Play	PLAY MODE ▶	Play		
⏯	Pause	⏸	Pause		
DVD SET UP REC LIST	Rec List/DVD	E-MANUAL D.MENU	D. Menu		
GOTO	Red/Goto	A	Red		
A-B	Green/A-B	B	Green		
ANGLE	Yellow/Angle	C	Yellow		
REPEAT	Blue/Repeat	D	Blue		